
Lighted TV Stand w/Fireplace Assembly Instructions



Before You Start

- A Please read all instructions carefully.
- A Retain instructions for future reference.
- ⚠ Separate and count all parts and hardware.
- A Read through each step carefully and follow the proper order.
- We recommend that, where possible, all items are assembled near to the area in which they will be placed in use, to avoid moving the product unnecessarily once assembled.
- Always place the product on a flat, steady and stable surface.
- A Keep all small parts and packaging materials for this product away from babies and children as they potentially pose a serious choking hazard.

Return / Damage Claim Instructions

⚠ DO NOT discard the box / original packaging.

In case a return is required, the item must be returned in original box. Without this your relurn will not be accepted.


If a replacement part is required, you will need to provide a photo of the part number. This helps our staff identify your product number and ensure you receive the correct part.


↑ Take a photo of the damaged part (if applicable).

A photo of the damage is always required to file a claim and get your replacement or refund processed quickly. Please make sure you have the box even if it is damaged.

⚠ Send us an email with the images requested.

Send us an email After-Sales-Service-Desk@outlook.com with the images requested and a description of your claim.





STEP 2

































4X





























STEP 14





Congratulations on doing it.