

REPLACEMENT PARTS LIST

When ordering parts, please be sure to furnish the following information on all orders. Failure to do so may delay your order.

1. Cooler model number
2. Cooler serial number
3. Motor HP
4. Description and part number
5. Date of purchase

No.	Description	4000 RLD4	4000 CRLD4
1.	Top Pan.....	220905-005	220905-005
2.	Bottom Pan	320908-005	320908-005
3.	Louvered Side Assembly	324111-106 (4)	324111-106 (4)
4.	Water Trough / <i>Canal De Agua</i>	226003-004 (4)	226003-004 (4)
5.	Pad Set	310101-4 (4)	310101-4 (4)
6.	Pad Retainers	224111-008 (12)	224111-008 (12)
7.	Corner Post.....	324003-013 (4)	324003-013 (4)
8.	Cut-Off Plate	224004-002	224004-002
9.	Blower Housing.....	324110-002	324110-002
10.	Blower Wheel.....	16BW	16BW
11.	Shaft, Blower Wheel	110183	110183
12.	Bearings, Blower Wheel Shaft	110351 (2)	110351 (2)
13.	Pulley, Blower Wheel	110275	110275
14.	Drive Belt	110212	110212
15.	Motor	110449	110449
16.	Pulley, Motor	110278	110278
17.	Motor Mount	314003-004	314003-004
18.	Motor Mount Clip Set	314005-001	314005-001
19.	Electrical Cord, Motor	110372	110372
20.	Float Valve	FL-C	FL-C
21.	Pump Mount	218001-031	218001-031 (2)
22.	Pump	110429	110429
23.	Pump Retainer	110714 (3)	110714 (6)
24.	Purge Pump	-	110429
25.	Pump Mount Extension Bracket.....	218001-033	218001-033 (2)
26.	Pad Retaining Strap Fastener.....	110611 (24)	110611 (24)
27.	Tube, Water Delivery	310716	310716
28.	Over Flow Assembly	110610	110610
29.	Water Distributor Assembly	3D-7	3D-7
30.	Holder, Water Distributor	110574 (8)	110574 (8)
31.	Electrical Junction Box	320106-003	320106-003
32.	Receptacle, Motor	110393	110393
33.	Receptacle, Pump	110361 (1)	110361 (2)
34.	Latch Assembly (2 Per Side)	318124	318124
35.	MasterStat Thermostat Controls	-	110423-2
36.	Liquidtight Conduit	-	110816
37.	Liquidtight Connectors	-	110817
38.	Bleed-Off Kit	310586	-

NOTE: Standard hardware items may be purchased from your local hardware store.

PARTS DRAWING

