

CARE AND MAINTENANCE

Store outdoor furniture indoors or cover well when not in use.

Remove wooden furniture from standing water. Dust regularly with small brush or vacuum

Spills should be taken care of immediately before they harden or stain with a slightly dampened sponge.

NOTICE












- * Please make sure that you have all parts indicated before you begin assembly of this item
- * This item should be assembled on a soft surface to prevent scratching the finish during assembly
- * This item may require periodic tightening




**Weight Capacity : 275 lbs (single seat)
550 lbs (two person seat)**



**Warning : Do not stand on bench
Warning : Do not over torque bolts/screws**

Part List and Hardware List



PIECE	DESCRIPTION	PICTURE	QUANTITY
1	LEFT CHAIR		1 X
2	RIGHT CHAIR		1 X
3	SEAT CHAIR		1 X
4	BACK CHAIR		1 X
5	SEAT CUSHION		1 X
6	BACK CUSHION		1 X
A	BOLT M6 x 60 MM		2 X
B	BOLT M6 x 40 MM		2 X
C	BOLT M6 x 20 MM		6 X
D	FLAT WASHER M6 x 1 MM		10 X
E	ALLEN KEY		1 X

Model# PAT7721
Product Dimensions
25.98"x31.10"x32.28"H (Chair)









STEP 1: Connect Left Chair (1) & Seat Chair (3), tighten Allen Bolt (C), Flat Washer (D) with Allen Key (E).



STEP 2: Connect Back Chair (4) & The Part from Step 1, tighten Allen Bolt (A), (B), Flat Washer (D) with Allen Key (E).



STEP 3: Connect Right Chair (2) & The Part from Step 3, tighten Allen Bolt (C), (A), Flat Washer (D) with Allen Key (E).



STEP 4: Put Seat Cushion (5), Back Cushion (6) to finish Chair.