
ASSEMBLY INSTRUCTIONS


ITEM NO. WF310106 - DINING TABLE

If you have any questions, please feel free to contact us. Email: lowes.team@qualfurn.net





IMPORTANT NOTE:


- 1) PLACE ALL PARTS ON A CLEAN AND SMOOTH SURF ACE SUCH AS A RUG OR CARPET TO AVOID THE PARTS FROM BEING SCRATCHED.
- (2) BEFORE TOU BEGIN, KINDLKY FOLLOW THE ASSEBLY INSTRUCTIONS STEP BY.
- 3 DO NOT TIGHTEN ALL SCREWS AND BOLTS UNTIL THE TABLE IS FULLY SET-UP.



| Part List For One | Hardware List For One |
|----------------------|-----------------------|
| A | Ø 5/16" x 38mm |
| TOP TABLE (1PC) | BOLT (4 pcs) |
| B | ② |
| SUPPORT BAR 1 (2PCS) | BOLT (18 pcs) |
| C | Ø 5/16" x 13mm |
| SUPPORT BAR 2 (4PCS) | FLAT WASHER (24 pcs) |
| D | Ø 5/16" x 19mm |
| LEG 1 (1PC) | LOCK WASHER (24 pcs) |
| E | 4mm |
| LEG 2 (2PCS) | ALLEN KEY (1 pc) |
| | |







STEP 7: Remove support bar STEP 8:

