


USER MANUAL

CEILING FAN LIGHT



Important: Please read and understand this manual before any assembly. Before assembling this product, please ensure that all parts are in place. Compare the details with the product display presentation. If you have any questions, don't hesitate to contact us.

Remote control instructions:

1. Install AAA batteries (Battery not included) . If the remote control is not used for a long time, please take out the battery to prevent battery damage .
2. The remote control function is shown below .



Link fan light (Normally, the remote control and fan light are already linked and can be used directly . If there is no link, follow the steps :
1. Turn off the main power supply to the fan light .
2. Turn on the main power of the fan light and press and hold this button within 5 seconds .
3. If you hear a beep, the remote is connected to the fan light . Try using a remote control to control the fan light .)



ALL OFF Turn off the lights and fans together

Turn on the light / Turn off the light

Turn off the fan

Lighten the lights/dim the lights

The light switches to night light mode

Turn down / up the color temperature of the light

Positive fan rotation / Fan reversal

Color temperature switch (white light, warm light, natural light)

Different fan speeds
1 gear has the least wind , 6 gear has the most wind.

Timing function 1H/2H


Mobile phone APP control instructions:

App Operation




1. APP download: Scan the QR code and select the APP version to download.
2. Pairing: After turning off the power of the fan light, then turn on the power, click the "PairCode" button on the APP within 5 seconds, and hear the beep, then the pairing is successful.
3. After the pairing is complete, you can control the device with the APP.

Note: APP connection method is Bluetooth.



Star-head Screwdriver	
Wire-stripping Pliers	
Stepladder	
Electrical Tape	



Specifications

The ceiling

