



ATTENTION

The air intake of the fireplace is behind the top of the glass. Do not block it!
This will cause overheating due to the lack of air circulation inside the cabinet.
Ensure the gap for air intake is at least 1/4 inch.



Gap for
air intake
1/4 inch



Gap for
air intake
1/4 inch



Gap for
air intake
1/4 inch

