

Assembly Instructions

Caution: You must read this before you proceed

Care & Maintenance

	• Not for commercial use. For residential use only.
	• Do not put hot items directly on furniture surface.
	• Do not clean furniture with harsh cleansers or polish.
	• Do not place furniture under direct sunlight.
	• Do not place furniture near heating or cooling vents.
	• Do not write on furniture without a padded barrier to protect the surface.
	• Do not place furniture outside . For indoor use only.
	• Stains may be removed with mild soap solution and damp cloth.
	• Children should not climb or jump on the furniture.
	• Dust and pick-up spills using a clean, non-colored, lint-free cloth.


Please look in Corners of carton for hardware packs and Legs.

Assembly Instructions

Please look in the Table for Hardware packs and Legs

Coffee Table




Item No: N735P464673



Caution: This Coffee Table is NOT a TOY. Keep your child / children at bay during the assembly process. Whenever lifting or moving the Table and to prevent damage to the Table, two adults may be needed to execute these actions.

ASSEMBLY INSTRUCTION

ITEM NO. N735P464673




ASSEMBLY INSTRUCTION

ITEM NO. N735P464673


Part List

Ⓐ




Top = 1pc

Ⓑ




Left Panel = 1pc

Ⓒ




Right Panel = 1pc

Ⓓ




Bottom = 1pc

Ⓔ




Middle Panel = 1pc

Ⓕ




Back Panel = 1pc

Ⓖ




Doors = 2pcs

Ⓗ




Front of drawer = 2pcs

Ⓘ




Left side of drawer = 2pcs

Ⓙ




Right side drawer = 2pcs

Ⓚ



Back of drawer = 2pcs

Ⓛ




Bottom of drawer = 2pcs

ASSEMBLY INSTRUCTION

ITEM NO. N735P464673

Hardware List




(1) Bolts 1/4" x 38 = 2 pcs




(2) Flat washer 12/6 x 1.5 = 2 pcs




(3) Spring washer 12/6 x 2 = 2 pcs




(4) Wooden dowel 8 x 30 = 20 pcs




(5) Cam Bolts 6 x 28 = 23 pcs



(6) Cam lock 15 x 9.5 = 23 pcs



(7) Metal Pin 6 x 20 = 4 pcs




(8) Flat head screw 4 x 25 = 8 pcs




(9) Allen Key K4 = 1 pc



Screwdriver (Not included)





Back




Front


Assembly Preparation Before Beginning Assembly:



(1) X 2 

(6) X 23 

(2) X 2 


(7) X 4 

(3) X 2 

(8) X 8 

(4) X 20 

(9) X 1 

(5) X 23 



Screwdriver (Not included)

Assembly Preparation

Before Beginning Assembly:



- Read instructions, cover to cover-



- Have 2 adults on hand for assembly-



- Do not assemble on flooring or carpet-





- Assemble on a clean non-marring surface (packing foam)-



- Save all packaging until finished-

Assembly Steps

Overview



FRONT FACING


This Coffee Table has multiple parts and may require up to 60 minutes to assemble. To give you an overview of the Table parts, the above picture is to help you put the various parts into perspective. Please read through the instructions below to familiarise yourself with the parts and steps before assembly.

BEFORE INSTALLATION


Caution: Please read the instructions thoroughly before assembly.

1. We recommend that you assemble this product with the assistance of another person; this will make the assembly easier, and will help eliminate damage to the product or injury to persons during assembly.
2. Please do not over tighten screws or bolts until the assembly is completed.
3. Please put all parts on a non-abrasive floor before assembly, and follow the assembly steps to assemble your newly purchased product correctly and efficiently.


Cam Lock Assembly Instructions




Insert Cam Bolt into hole as shown in diagram A.




Make sure not to insert the Cam Bolt: Too deep as shown in figure B as this will cause the Cam Lock to be misaligned and unable to interlock properly.




Also avoid inserting the Cam Bolt too close to the surface of the hole as shown in figure C, as this will cause the Cam Lock to be too loose, and not interlock properly.



Connect the panels together.



Insert the Cam Lock so the side opening fits over the head of the Cam Bolt.



To tighten the Cam Lock, turn it clockwise on half a turn with a flat screwdriver.
**Do not use an automatic screwdriver as it may bend or break if too much power is imposed.*


Step 1 Unpack and place the all parts face up on a clean, flat surface to avoid scratches.
Attach the Cam Bolts (5) into the Top (A), Left Panel (B), Right panel (C) and the Front of Drawer (H)
Using the Screwdriver (Not included) to tighten securely.




ASSEMBLY INSTRUCTION

ITEM NO. N735P464673

Step 2 Attach the Metal Pin (7) into Right Panel (C), Left Panel (B) and Middle Panel (E) by hand as picture.



Step 3 Attach the Left Side Panel (B) to the Bottom Panel Assembly (D), aligning the holes with Wooden Dowels (4). Then use the Cam Locks (6) and a screwdriver (not included) to tighten securely.



TOOLS REQUIRED



Screwdriver
(Not included)

Wooden dowel
8 x 30



④ x 2

Camlock
15 x 9.5




⑥ x 3


ASSEMBLY INSTRUCTION

ITEM NO. N735P464673

Step 3 Attach the Door (G) onto the Left Side Panel (B) so that the door's sliding groove aligns with the metal Pin (7) as picture.




Step 4 Attach the Middle Panel (E) to the Bottom Panel (D), so that the door's sliding groove aligns with the metal Pin (7) as Step 3. aligning the holes with Wooden Dowels (4). Then use the Bolts (1) + Spring washer (2) + Flat washer (3) and Allen Key (9) to tighten securely.



ASSEMBLY INSTRUCTION

ITEM NO. N735P464673

Step 5 Attach the Door (G) onto the Middle Panel (E) so that the door's sliding groove aligns with the metal Pin (7) as step 3.




Step 6 Attach the Right Side Panel (C) to the Bottom Panel (D), aligning the holes with Wooden Dowels (4) while ensuring that the metal pin (7) installed in step 2 aligns with the groove on the door (G). Then use the Cam Locks (6) and a screwdriver (not included) to tighten securely.

TOOLS REQUIRED



Screwdriver
(Not included)

Wooden dowel 8 x 30	Camlock 15 x 9.5
④ x 2	⑥ x 3




ASSEMBLY INSTRUCTION


ITEM NO. N735P464673

Step 7 Now grab a friend and carefully rotate the unit so that it's facing up.

Attach the Back panel (F) into the grooves between the Left Side panel (B), Right Side Panel (C) and Middle panel (E)



Step 8 Attach the Top Panel (A) onto the Left side Panel (B), Right side Panel (C) and Middle Panel (E), aligning the holes with Wooden dowel (4), then Using the Cam Locks (6) and a screwdriver (not included) to tighten securely.



Wooden dowel
8 x 30



(4) x 6

Camlock
15 x 9.5



(6) x 9

TOOLS REQUIRED



Screwdriver
(Not included)

ASSEMBLY INSTRUCTION

ITEM NO. N735P464673

Step 9 Attach the Left of drawer (I) and Right of Drawer (J) into Back of drawer (K). Align by Wooden dowel (4). then Using the Flat head screw (8) and a screwdriver (not included) to tighten securely. Repeat the same steps for the second drawer.

TOOLS REQUIRED



Screwdriver
(Not included)

Wooden dowel
8 x 30




(4) x 8

Flat head screw
M4 x 25




(8) x 8



Step 10.1 Attach the Bottom of drawer (L) into the grooves of Left side drawer (I) and Right side drawer (J). Back of drawer (K) assembled in Step 9

Step 10.2 Attach the Front of Drawer (H) to the drawer frame assembly completed in Step 9. Position it using the cam bolts (5) installed in Step 1, then use cam locks (6) and a screwdriver (not included) to tighten securely.



TOOLS REQUIRED



Screwdriver
(Not included)

Camlock
15 x 9.5



(6) x 8


ASSEMBLY INSTRUCTION

ITEM NO. N735P464673

Step 11 Install the 2 drawers full assembly in Step 10 into the front of Coffee Table.

(the side with the pre-installed drawer slides).


- Carefully align the drawer slides with the cabinet slides..
- Insert the drawer into the slides and push it inward slowly until both roller wheels engage properly.
- Pull the drawer in and out several times to check for smooth operation and proper alignment.




Step 12 Check for wobbles on a LEVEL surface.

Your Coffee Table is ready for use,


This Coffee Table can only be used on the flat, level surface



Normal



Only open the Drawers



Open the Drawers and the Doors