

ASSEMBLY INSTRUCTIONS

ITEM NO. FB3035HAY-SC-4PK




ITEM NO. FB3037HAY-SC-4PK









ASSEMBLY TIPS:


1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.

Part List


NO.	DIAGRAM	PART NAME	Q'ty
#1		Back frame with cushion	4 pcs
#2		Seat frame with cushion	4 pcs
#3		Front Legs	8 pcs

Hardware List


NO.	DIAGRAM	PART NAME	Q'ty
#A		Bolt 5/16" x 3"	16 pcs
#B		Bolt 5/16" x 2-1/4"	16 pcs
#C		Bolt 5/16" x 1-3/4"	4 pcs
#D		Spring washer Ø5/16"	36 pcs
#E		Flat washer Ø5/16"	36 pcs
#F		Allen key M5	4 pcs



STEP 1:




STEP 2:




Do not tighten screws until completely assembled.

STEP 3:



STEP 4:



Tighten all screws until completely assembled.