



## GREEN DECORATIVE FROG CERAMIC TABLETOP FOUNTAIN

### SSS-485

Read the assembly instructions carefully and follow the care instructions. Keep these instructions for future reference.

**Assemble components of this fountain on a soft, clean surface to avoid scratching or damaging the finish.**



Inspect packaging to ensure all parts are accounted for before disposing of packaging.

### ASSEMBLY

PARTS	QTY.
Fountain Topper	1
Fountain Base	1
Electric Submersible Pump	1

1. Attach the pump to the tubing that is built into the fountain topper.
2. Gently place the fountain topper onto the fountain base.
3. Fill the fountain with enough water to keep the pump fully submerged during operation.
4. Plug the power cord into an electrical outlet.

**Note:** When first used, there may be air in the pump. It may take several minutes for trapped air to escape, allowing water to flow.



## IMPORTANT INFORMATION



### USE & CARE

- **INDOOR USE ONLY.**
- Check the water level frequently to ensure the pump remains fully submerged; never allow the pump to run dry as it will burn out the motor.
- Only use water in this fountain; distilled water is recommended to prevent mineral buildup.
- Periodically change the water to keep the water, fountain and pump clean. Remove scale and build-up regularly.  
DO NOT use harmful additives such as bleach, chlorine, etc.  
DO NOT use anything abrasive to scrub the fountain.
- Always shut off the power supply before cleaning and maintaining the fountain and the recirculating pump.
- Take care when handling the pump; only pick it up by the body of the pump, never the power cord.

### TROUBLESHOOTING

- Ensure that the pump is fully submersed and add water to the basin if necessary.
- Check to make sure the power outlet is working; if in doubt about electrical connections, consult a certified electrician.
- Check the pump and tubing for obstructions.
- Check the flow control on the body of the pump as it may need to be adjusted to achieve the desired flow rate.
- If water is not flowing within several moments of the fountain being plugged in, unplug the power supply for a few moments and plug it back in; the pump may have air bubbles in the filter which can prevent water from circulating properly.

**Any modification or failure to follow the recommended care will void the product warranty.**