


highmore

Rocko

Motorized Height Adjustable Workbench With Pegboard

User Manual



Product Ref-HM-WB001-001

Imported By: Forward Industries, 33401. U.S.A

Safety and Care Advice

1. The maximum weight that can be placed on this product is 507lbs.
2. This product must not be used as a seat.

Specifications

Power Supply: AC adapter, 100-240V~ 50/60Hz

Service Environment: 32-104°F

Important Safety Instructions

When using an electrical furnishing, basic precautions should always be followed, including the following:
Read all instructions before using (this furnishing).

DANGER – To reduce the risk of electric shock:

1. Unplug the power plug before cleaning, wipe the dust on surface with damp cloth when cleaning. Be careful not to let water drops into the internal parts, or loose the connector.
2. Check carefully to ensure correct and complete assembly before using.
3. Be familiar with all functions and program settings of the product before first use.
4. Don't allow children to play near the desk as their behavior is unpredictable. The manufacturer is not responsible for loss, injury, or damage due to those improper action.
5. The slight noise caused by the internal mechanism or brake system of the structure, will not have any effect on the use of the equipment.
6. Do not use corrosive or abrasive materials are near the equipment. Please ensure that the cleaner used will not pollute the environment.
7. Children are forbidden to play on the product because of unforeseen action when playing, so any dangerous consequences caused by this improper action will not be on manufacturers.
8. Cleaning and user maintenance should not be attempted by children without supervision.
9. If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or a similarly qualified person in order to avoid a hazard.
10. Please make sure there is no hazard sources in your operating environment. e.g., do not litter the tools around. Always be careful to treat the packaging materials in order to avoid any possible danger, e.g. plastic bag may lead to choking hazard to children.
11. We recommend you keep the original package of the equipment if necessary in case of the future use in transportation.
12. Do not use outdoors.

13. Unplug from outlet before putting on or taking off parts.
14. Use this furnishing only for its intended use as described in these instructions. Do not use attachments not recommended by the manufacturer.
15. Never operate this furnishing if it has a damaged cord or plug, if it is not working properly, if it has been dropped or damaged, or dropped into water. Return the furnishing to a service center for examination and repair.
16. Keep the cord away from heated surfaces.
17. To disconnect, turn all controls to the off position, then remove plug from outlet.
18. For grounded products the following statement:
"WARNING: Risk of Electric Shock – Connect this furnishing to a properly grounded outlet only. See Grounding Instructions."
19. For loading always put heavier items at the bottom and not near the top in order to help prevent the possibility of the furnishing tipping over.

SAVE THESE INSTRUCTIONS


For Household use only

SERVICING OF DOUBLE-INSULATED PRODUCTS


In a double-insulated product, two systems of insulation are provided instead of grounding. No grounding means is provided on a double-insulated product, nor is a means for grounding to be added to the product. Servicing a double-insulated product requires extreme care and knowledge of the system, and is to be done only by qualified service personnel. Replacement parts for a double-insulated product must be identical to the parts they replace. A double-insulated product is marked with the words "DOUBLE INSULATION" or "DOUBLE INSULATED." The symbol (square within a square) is also able to be marked on the product.

Main Components


Please check you have all the parts listed below




1 Table Top Qty 1
(47.2*23.6*1.0")




2 Leg(Motor) Qty 1
(27.4*2.0*3.1")




3 Leg Qty 1
(27.4*2.0*3.1")




4 Foot Qty 2
(23.6*2.8*1.2")



5 Controller Qty 1
(2.0*2.5*0.5")



6 Leg Support Qty 1
(34.8*5.9*3.0")



7 Transmission Cover Qty 1
(28.1*2.7*1.2")




8 Transmission
Connector Qty 1
(ϕ 0.6*4.9")



9 Transmission rod Qty 1
(23.6")

Main Components

Please check you have all the parts listed below




10 Power cable Qty 1
(122")



11 Pegboard Support
(left) Qty 1
(25.6*7.9*0.8")



12 Pegboard Support
(right) Qty 1
(25.6*7.9*0.8")













13 Peg board Qty 2
(43.9*5.9*0.8")


Fixings, Fittings And Tools

Please check you have all the fittings listed below

Note: The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.

<p>A</p>  <p>M5 Screw Qty 2 (M5*0.24")</p>	<p>B</p>  <p>M6 Screw Qty 4 (M6*0.31")</p>	<p>C</p>  <p>M6 Screw Qty 20 (M6*0.63")</p>
<p>D</p>  <p>M8 Screw Qty 4 (M8*0.63")</p>	<p>E</p>  <p>Spring Washer ϕ0.24" Qty 12</p>	<p>F</p>  <p>3M Cable Clip Qty 4 (0.69*2.56")</p>
<p>G</p>  <p>M6 Screw Qty 8 (M6*1.18")</p>	<p>H</p> <div style="display: flex; justify-content: space-around; align-items: flex-end;"> <div style="text-align: center;">  <p>2.5x2.5 (0.1*0.1*2.01")</p> </div> <div style="text-align: center;">  <p>Spanner (5.12*0.98*0.28")</p> </div> <div style="text-align: center;">  <p>4x4 (0.16*0.16*2.44")</p> </div> </div> <p>Allen key Qty 1</p>	

Not Supplied




If you have questions regarding the operation of your purchase, or in the unlikely event you need to return the unit because it is faulty or is no longer wanted, please contact our product returns department at customerservice@forwardindustries.com, or 561-465-0030, Option 0.

Address: Forward Industries, 105 South Narcissus Avenue Suite 412, West Palm Beach, FL 33401

Assembly Steps

STEP 1

Assemble legs **2** and **3** to the underside of table top **1** using screws **C**.



C



M6 Screw Qty 8

H



4x4 Qty 1




IMPORTANT

During assembly, ensure the height of the legs remains the same on both sides!

SHOWN UPSIDE DOWN

STEP 2

Assemble feet **4** to legs **2** and **3** using screws **G**.



G



M6 Screw Qty 8

H








4x4 Qty 1

SHOWN UPSIDE DOWN

Assembly Steps

STEP 3

- a. Slide transmission connector **8** onto one end of transmission rod **9**.
 - b. Locate the other end of transmission rod **9** into the hole in the side of leg **3**.
 - c. Slide transmission connector **8** back, until it is equally located between transmission rod **9** and the short transmission rod in leg **2**.
 - d. Secure using grub screws **A**.
- IMPORTANT**-Ensure the legs **2** and **3** remain at the same height throughout.



M5 Grub Screw Qty 2






2.5x2.5 Qty 1

SHOWN UPSIDE DOWN

Assembly Steps

STEP 4

Assemble transmission cover **7** in between legs **2** and **3** using screws **B**.



B



M6 Screw Qty 4






H



4x4 Qty 1

STEP 5

- Remove the caps on each end of leg support **6**.
- Ensuring the small holes are facing up as shown, assemble leg support **6** to the back of legs **2** and **3** using screws **D**.
- Replace the caps into leg support **6**.



D



M8 Screw Qty 4

H




Spanner Qty 1

SHOWN UPSIDE DOWN


Assembly Steps

STEP 6

Assembly controller **5** to the underside of the table top (front) using the screws supplied with the controller.





Not Supplied



SHOWN UPSIDE DOWN

STEP 7

Complete all cable connections as shown. Cable tidy clips **F** can be used to route and secure cables as required.



SHOWN UPSIDE DOWN



Assembly Steps

STEP 8

With help, stand the desk upright.

⚠ Warning the desk is heavy, lift with care.



Assemble pegboard supports **11** and **12** to the underside of table top **1** using screws **C** and spring washers **E**.




STEP 9

With help, locate pegboards **13** in between supports **11** and **12**.

Secure using screws **C** and spring washers **E**.




SHOWN FROM BACK



Height Adjustment/Controls

Controller



Up and DOWN Function

Press the “▲” or “▼” keys to raise or lower the desk top.

Reset Function

- (1) Reset: press “▼” key until the desk reaches its lowest height and rebounds to stop, it means the reset has been completed.
- (2) If other problems occur, please check the cable connection and then cut off the power for at least 10 seconds. Reconnect to the power and press “▼” key to start the reset process.

Troubleshooting

The following tips will help you detected and eliminate the common faults and errors. If the fault you met is not listed below, please contact our after sales team. Only the manufacturer can investigate or resolve faults or errors not listed below.

Fault phenomenon	Method
No response while long pressing down arrow after connected with a power supply	1.Check if all the cables be connected well
	2.Contact your supplier or dealer
Bottom cannot rise	1.Check if the equipment load is too heavy to exceed 230KG
	2.Contact your supplier or distributor
Overwork (Duty cycle: Max 2min on/30min OFF)	1.Restart after suspend for 30 mins while connecting with power;
	2.Contact your supplier or dealer;

After Sales Support / Product Returns

If you have questions regarding the operation of your purchase, or in the unlikely event you need to return the unit because it is faulty or is no longer wanted, please contact our product returns department at customerservice@forwardindustries.com, or 561-465-0030, Option 0.

Address: Forward Industries, 105 South Narcissus Avenue Suite 412, West Palm Beach, FL 33401

Disposal



This marking indicates that this product should not be disposed with other household wastes. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. They can take this product for environmental safe recycling.

Certification



RoHS