
Assembly Instructions



Model No.

Two-Person Desk

HOGA-YS0183/YS0337 HOGA-YS0262/YS0270 HOGA-YS0321/YS0320 HOGA-YS0366


Contact Us We're here to help you.



Your satisfaction is our top priority. If you encounter any issues with this product, such as missing or damaged parts, we're here to help. Please retain the original packaging and take photos of the packaging and the product, then contact us as soon as possible.


Warm Tips

- 1. Carefully read these instructions and keep them for future reference.
- 2. Check the parts list and confirm everything's there before starting assembly.
- 3. When assembling, put all parts on a soft, smooth surface like a carpet to avoid scratches.
- 4. Don't fully tighten screws until all parts are confirmed in place to avoid misalignment.




We recommend using hand tools for assembly.


If an electric screwdriver is used, reduce power and torque to avoid damage to the product.



AVOID SCRATCHES

In order to avoid scratching, this furniture should be assembled on a soft surface, such as a rug.








Make sure all parts are included. Most board parts are labeled or stamped on the raw edge. Contact us for a free replacement if you encounter any damaged or missing parts.

Parts List





Hardware List


Α	В	С	D	E
M8	M6×12mm	M6×60mm	M6×25mm	M6×50mm
4pcs	12pcs	8pcs	4pcs	8pcs


F	G	Н	1	
			M4 M10	
M6×40mm	Ø8×30mm	M6		
12pcs	3pcs	4pcs	1pc	



































Thank you for your support!

