




Pro 42in Outdoor Kitchen Cabinet Station XL



Model: MC810

SKU: 40013

NUUK USA
nuukusa.com



Table of Contents

It is the consumer's responsibility to see that the unit is properly assembled, installed, and maintained. Failure to follow the instructions in the manual could result in bodily injury and/ or property damage

Table of Contents	- page 2
Safety Information	- page 3
Customer Support Care and Maintenance	- page 4
Exploded View	- page 5
Parts	- page 6 – 7
Assembly Instructions	- page 7 – 18
Warranty	- page 19



Safety Information

IMPORTANT: ALL INSTRUCTIONS AND SAFEGUARDS IN THIS SECTION MUST BE FOLLOWED TO PREVENT DAMAGE AND/OR INJURY.

- Not for permanent installation.
- For outdoor use only
- Use caution with all electric appliances, tools, extension cords and lights on and around table.
- Surface can become hot in direct sun or high temperatures.
- Maximum top weight load of 60 LBS
- Maximum shelf weight load of 30 LBS
- Use only on level surfaces.
- Before use ensure wheels are height adjusted so that the table does not rock when in use.
- Lock wheels when in use.
- Do not allow children to climb the product.

CALIFORNIA PROPOSITION 65 WARNING

WARNING: This product can expose you to lead, which is known to the State of California to cause cancer and birth defects or other reproductive harm. For more information go to www.P65warnings.ca.gov



Customer Support

**HAVE PROBLEM / QUESTION/ CONCERN
NO WORRY!**

Our Customer Service Staff is Here To Help You!

For questions regarding your NUUK products, installation, replacement parts or your warranty, please contact

NUUK customer service team.

Phone: 1-800-719-8199
Monday through Friday
9:00 am to 5:00 pm, Eastern Time Zone

Email: service@nuukusa.com

Care and Maintenance

CLEANING

Painted and Plastic Surface

Wash with mild detergent or non-abrasive cleaner and warm Water.


Stainless Steel Surface

Wash with mild detergent and warm soapy water or use stainless steel cleaner. Wipe dry with a soft cloth after each use.

Wash only in the direction of the stainless brushed finish to avoid damage.

Stainless steel can rust under certain conditions. This can be caused by acidic marinades, chlorine, saltwater, exposure to coastal climates, other natural elements, or improper cleaning tools such as wire or steel wool.

NUUK™ Exploded View











If you find any missing parts, damage parts, please contact NUUK

Phone: 1-800-719-8199
Monday through Friday
09:00 am to 05:00 pm, Eastern Time Zone

Email: service@nuukusa.com

NUUK™ Parts


PART		DESCRIPTION	QTY	PART		DESCRIPTION	QTY
1		Countertop	1	12		Cart Handle	1
2		Tools Holder	1	13		"S" Hook	4
3		Middle Shelf Rail-L	1	14		Front Beam	1
4		Middle Shelf Rail-R	1	15		Caster Wheel	4
5		Middle Shelf	1	16		Front Door (R)	1
6		Sealing Plate	1	16A		Front Door (L)	1
7		Condiment Tray	1	16B		Tools Hook	3
8		Back Panel	1	17		Door Axle	2
9		Leg-L	1	18		Bottom shelf	1
10		Leg-R	1	19		Wood Cutting Board	1
11		Bottle Opener	1	20		Middle Panel	1

PART		DESCRIPTION	QTY
21		Cutting Board Holder	2
22		Metal Tray	1

PART		DESCRIPTION	QTY
23		Beam Connector	1
24		PVC Liner	1

Hardware and Assembly Instructions

Hardware

PART		DESCRIPTION	QTY
A		Bolt M6x12	63
C		Bolt M6X25	1
E		Axle Holder	2
G		Nut M5	2


PART		DESCRIPTION	QTY
B		Bolt M4x12	10
D		Washer	1
F		M5 Step Screw	2
H		Flat Washer	2



A x 8

STEP 1

Connect Leg-R (10) and Leg-L (9) to bottom shelf (18), using 8 pcs Bolt M6 x 12 (A)




Pay attention to the direction of the sticker



A x 16

STEP 2

Attach 4 casters wheels (15) onto leg, using 16 pcs Bolt M6 x 12 (A)






A x 6

STEP 3

Install back panel (8), using 6 pcs Bolt M6 x 12 (A)




A x 2

STEP 4

Install Middle Panel (20) onto bottom shelf, using 2 pcs Bolt M6 x 12 (A)

NOTE: Flat side face to right side, or, magnet face to front side







A x 1

STEP 5



Connect middle shelf to back panel, using 1 pc Bolt M6 x 12 (A)



A x 4

STEP 6


Install front beam (14) onto legs, using 4 pcs Bolt M6 x 12 (A)






STEP 7

Install beam connector (23) to secure middle panel and front beam, using 2 pcs Bolt M6 x 12 (A)



STEP 8

Install middle shelf rail-L (3) onto left side of leg, using 2 pcs Bolt M6 x 12 (A)
 Install middle shelf rail-R (4) onto right side of leg, using 2 pcs Bolt M6 x 12 (A)






STEP 9

Install sealing plate (6), using 4 pcs Bolt M6 x 12 (A)


NOTE: Line up from back of cart.



STEP 10

Following below step to install door


1. Insert Axle holder (E) into the hole on bottom shelf(front corner of bottom shelf)
2. Place the door (16) & (16A) into the position
3. Hold the door axle (17), follow below step to install door axle.






STEP 11

Install tools hook (16B) onto left side door (inside), using 6 pcs Bolt M4 x 12 (B)



STEP 12

Slide in middle shelf (5), using 2 pcs M5 Step Screw (F) & 2 pcs M5 Nut (G) and 2 pcs Flat washer (H) to secure on the rail






A x 8

STEP 13

Install countertop (1) onto the assembled cart, using 8 pcs of Bolt M6 x 12 (A)


NOTE: Logo face to front



A x 2

STEP 14

Attach bottle opener (11) onto front of left leg, using 2 pcs Bolt M6 x 12 (A)





A x 2



C x 1



D x 1

STEP 15



Attach tools holder (2) onto left side of counter top, using 2 pcs Bolt M6 x 12(A)

NOTE: Please do not tighten the screw right now!



Insert washer (D) at the middle of holder, line the hole, using 1 pcs Bolt M6 x 25 (C) to secure the washer.

PLEASE tighten all three bolts at this time


STEP 1



STEP 2



STEP 3





STEP 16



Pre-assemble 2 pcs Bolt M6 x 12 (A) onto left side leg.

DO NOT TIGHTEN THE BOLT


Hang condiment tray (7) on those pre-assemble bolt, then secure the tray by another 2 pcs Bolt M6 x 12(A)

Finally, tighten all 4 bolts!

STEP 1



STEP 2



STEP 17



Pre-assemble 2 pcs Bolt M6 x 12 (A) onto right side leg.

DO NOT TIGHTEN THE BOLT


Hang cart handle (12) on those preassemble bolt, then secure the handle by another 2 pcs Bolt M6 x 12 (A)

Finally, tighten all 4 bolts!

STEP 1




STEP 2



STEP 18A

Install cutting board holder (21) onto middle panel and right side leg panel.

Suggest to use the middle position hole.




STEP 18B

Put the wood cutting board (19) on the holder.


NOTE:

- You can adjust the height of cutting board, there are total 3 difference position, please make sure you will adjust both holder together.
- Cutting board can use for shelf, also can be taken out to prepare food




STEP 19

Attach the metal tray (22) on right side door, there are preset holder located inside of right side door



STEP 20

Put S hooks (13) on cart handle







Assembly Instruction

STEP 21

Place PVC Liner(24) on the bottom shelf. Cover the tank hole, avoid missing during moving cart. When you keep propane tank inside the cart, please move PVC Liner(24) to slide middle shelf.



FINISH PRODUCTS



NOTE :

For Model: MC810 (SKU: 40013)



Warranty

NUUK LLC (NUUK USA) 1-YEAR WARRANTY

Proof of purchase is required to access this warranty program, which is in effect from the date of purchase.

NUUK USA warranty covers one year from the date of purchase. NUUK will assist you to get the replacement parts, replace the unit. All warranties are limited to the original purchase only. This warranty does not cover any liability for used good purchase. The purchaser must follow the usage instruction.

Warranty Provisions

- This warranty is non-transferable and does not cover failure due to misuse, improper installation or maintenance.
- This warranty is for replacement of defective parts only. We are not responsible for incidental or consequential damages or labor costs.
- This warranty does not cover damage caused by abrasive or chemical cleaners, or any damage to other components used in the installation or operation of the table.

- Paint is not warranted and may require touch-up.

NUUK customer service team

Phone: 1-800-719-8199
Monday through Friday
9:00 am to 5:00 pm, Eastern Time Zone

Email: service@nuukusa.com

NUUK USA
nuukusa.com