

Parker Porch Swing with Canopy



For assistance with assembly, please contact customer service
(814) 349-4499











PRE-ASSEMBLY PREPARATION:






DO NOT LET CHILDREN PLAY IN OR AROUND THE UNIT DUE TO THE POSSIBLE RISK OF FINGER ENTRAPMENT

- Please read through these instructions before beginning assembly.
- Two adults are recommended for assembly.
- Clear out an open space for assembly and lay all items on the Parts and Hardware List on a padded surface to protect the finish. Extra room will allow you to easily determine if all the pieces are present.
- Save all packing materials until assembly is complete to avoid accidentally discarding smaller parts or hardware.
- Keep small parts and pieces away from children until fully assembled.
- Please check for any loose screws and tighten them before you use.




PARTS LIST:

ID	PHOTO	DESCRIPTION	QTY
A		Front Leg	2
B		Back Leg	2
C		Top Rail	1
D		Swing Frame	1
E		Right Arm	1
F		Left Arm	1
G		Leg Brace	1
H		Hanging Bar (Front)	2
I		Hanging Bar (Back)	2
J		Canopy Rail (Middle)	1
K		Canopy Rail (Sides)	2
L		Canopy Brace	2

PARTS LIST: (Continued)

ID	PHOTO	DESCRIPTION	QTY
M		Canopy	1
N		Seat Cushion	1
O		Back Cushion	1

HARDWARE LIST:

ID	PHOTO	DESCRIPTION	QTY
1		M8 x 60mm Bolt	2
2		M8 x 15mm Bolt	2
3		M8 x 45mm Bolt	4
4		M6 x 60MM Bolt	4
5		M8 Washer	8
6		M6 Washer	4
7		M8 Nut	8
8		M6 Nut	4
9		M8 Lock Nut	8
10		M6 Lock Nut	4
11		Spring	2
12		Knob	2


TOOLS LIST:


Allen Wrench (Included)


Spanner (Included)

STEP-BY-STEP ASSEMBLY:

- 1** Attach the Front Leg (A) to Back Leg (B) using two sets of M8 x 60mm Bolts (1), M8 Washers (5), M8 Nuts (7) & M8 Lock Nuts (9). Then attach the Top Rail (C) in between the Legs using four sets of M8 x 45mm Bolts (1), M8 Washers (5), M8 Nuts (7) & M8 Lock Nuts (9). Tighten the Bolts & Nuts using the Allen Wrench & Spanner provided.




- 2** Attach the Leg Brace (G) in between the Legs using four sets of M6 x 60mm Bolts (4), M6 Washers (6), M6 Nuts (8) & M6 Lock Nuts (10). Tighten the Bolts & Nuts using the Allen Wrench & Spanner provided.



4		x4	8		x4
6		x4	10		x4


STEP-BY-STEP ASSEMBLY:

- 3** Attach the Right Arm (E) & Left Arm (F) to the Swing Frame (D) using two M8 x 45mm Bolt (3) and tighten using the Allen Wrench provided.



3		x2
---	--	----


- 4** Attach the Front Hanging Bar (H) to the Arms using two M8 x 15mm Bolts (2). Attach the Back Hanging Bar (I) between the Arms and back of Swing Frame using two M8 x 45mm Bolt (3). Tighten the Bolts using the Allen Wrench provided.



2		x2
3		x2


STEP-BY-STEP ASSEMBLY:

- 5** Insert Springs (11) into holes on both the Front & Back Hanging Bars (H) & (I). Then carefully position the Swing to the swing stand and attach it by hooking the Springs into the ring on the Top Frame (C).




11		x2
----	---	----

- 6** Insert Canopy Rails (J) & (K) into pockets on the Canopy (M).




STEP-BY-STEP ASSEMBLY:

- 7** Attach the two Canopy Braces (L) into the Canopy Rails by inserting the ends into slots. Stretch out the Canopy (M) to secure it into the Canopy Frame. Then carefully position the Canopy on top of the stand and secure by fastening with the Knob (12) through holes on the Canopy Braces & Top Frame.



- 8** Place the Seat Cushion (N) & Back Cushion (O) on the Swing.



Missing or damaged parts? Please contact customer service at (510) 983-4310.
Our promise - your call will be returned.

WARNING: California's Proposition 65

This product can expose you to chemicals including wood dust, which is known to the State of California to cause cancer. For more information go to www.P65WARNINGS.ca.gov/furniture