

E-Commerce

ASSEMBLY INSTRUCTIONS

MODEL # FGI-2394C26

Questions?

GIVE US A CALL: 1-888-980-5122 MON – FRI 8:30AM – 5:30PM (PST)

TOOLS REQUIRED



(Not Included)



Philips Screwdriver (Not Included)




2 - People Recommended





The Assembly Rating is a 5-point system showing the level of effort needed to assemble a specific product.








Thank you for your purchase!

We hope you enjoy this new addition to your home for many years to come.

Our commitment to providing quality products does not simply end when you purchase our product. We fully stand behind our products from start to finish. Our customer service department is available Monday – Friday 8:30 AM – 5:30 PM Pacific and can help with assembly questions as well as, if necessary, replacing damaged or missing parts. To help expedite our service, please have these assembly instructions readily available, along with your order receipt.



PRE ASSEMBLY

We understand building ready-to-assemble furniture can be a challenging experience for some. To help avoid confusion, we have provided some helpful tips that may speed up the process.


















Teamwork

ALWAYS have at least two people to help with transporting and assembling the product to avoid potential injury and/or damage.

Suitable Location

Assembling near the area of the intended location is highly recommended.

Sufficient Space

Make sure you have enough space to move around during the assembly.

Avoid Scratches

Use cardboard, blankets or a carpeted area while assembling furniture to prevent scratches.


Flat Surface

Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.

ASSEMBLY AND CARE ADVICE



FAILURE TO FOLLOW THE GUIDELINES BELOW MAY RESULT IN INJURY AND/OR PROPERTY DAMAGE.



Save the instructions and store any supplied tools for later maintenance. After two weeks, check and tighten any loose hardware and repeat again every six months thereafter.

IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.

CAM LOCK FASTENER ASSEMBLY INSTRUCTIONS


Note :

Every cam lock bolt must have a cam lock connector in order to fasten the parts together.










Screw the cam bolt into panel.




Align the cam lock with its side opening (or arrow) pointing to cam bolt.


cam bolt

cam lock





Insert the cam bolt into the bolt hole of joint panel.



Turn the cam lock clockwise gently until it will not turn any more.


COFFEE TABLE


FGI-2394C26

- Please keep instructions for future reference.
- Check the quantity and irregularity of parts and hardware before you start.


B1PC

●1PC







PARTS



1PC



€1PC





©1PC





HARDWARE					
1) 8PCS	(2)8PCS 0.47"	③10PCS 0.98"			
④ 10PCS 1.57"	(5)6PCS	666PCS			

ACCESSORIES					
A1)6PCS	A21PC	A31PC	A4)1PC	A51PC	
\bigcirc					
A6 3PCS	A7 6PCS				
STA B	00000				









6

ASSEMBLY COMPLETED



Keep this handy!

Please retain this instruction manual and any order-related information for future reference.

(v) Lift, don't drag!

To avoid damage to product please always LIFT the product when transporting or adjusting the placement.

