

Animated Figurine Assembly Instructions

The model number of your figurine is printed on the side of your carton.
Always use this number to identify your model.

Thank you for your purchase of this quality holiday decoration. With proper use and care, your figurine will provide you with years of enjoyment. Please follow the instructions on how to assemble and disassemble.

If you should have any problem with your decoration, DO NOT return it to the place of purchase. Please call our toll free number below and a customer service representative will assist you. Enjoy your holiday!

Customer Service: 1-855-591-7451 (9am to 5pm, Monday through Friday)

Your Package Includes:

Two-Piece Figurine & 1 Transformer


This product is for indoor use only. Do not place in direct sunlight.

This product operates with 5V isolating transformer. Only use with the 5V transformer supplied.

Please read all instructions completely before assembling your figurine.


Assembling the figurine:

1. Remove all parts from packaging carefully. **Use caution with sharp tools.**
2. Stand figurine body upright on sturdy surface.
3. Turn the white cap on the neck counterclockwise to release the legs from under the body cavity. **Keep a firm grip on the shoulders to prevent the body from releasing quickly.**



Attaching the Transformer:

1. Insert the jack into the white base.
2. Straighten out the clothes and fluff up any accessories.
3. Insert the transformer into the power socket.



NOTE: The figurine will begin movement when the sensor detects someone is more than 20 inches away.



Warnings

1. This product is for decoration only and is not a toy. Please keep out of reach of small children.
2. Do not position the figurine near candles, sources of heat, or in direct sunlight.
3. The figurine cannot be connected to the power supply directly.
4. Do not break, cut, or alter the power cable.
5. Do not attempt to repair the wiring with staples or nails.
6. Do not place the cable under a carpet or rug as it may get damaged.
7. Ensure that the cable is in a secure location where it is not a hazard.
8. Do not connect the figurine to the power supply while it is still in the packaging.
9. Please switch off the transformer when not in use.
10. Do not leave figurine unattended while operating in the ON position.
11. Do not over load the transformer.
12. Figurine should be on a level, stable surface to prevent it from falling over.

Storage tips: You may want to save the carton for storing your figurine. Store in a cool, dry area where the temperature does not exceed 100°F.