

MODEL#

SL3401-PT-3PK

Questions?

E-MAIL: inquirySSL88@gmail.com MON-FRI 8:30AM - 5:30PM (PT)

TOOLS REQUIRED





Screwdriver (Not included)



Allen Wrench



2 - People

ASSEMBLY RATING



EASY DIFFICULT


The Assembly Rating is a 5-point system showing the level of effort needed to assemble a specific product.




Thank you for your purchase!

We hope you enjoy this new addition to your home for many years to come.

Our commitment to providing quality products does not simply end when you purchase our product. We fully stand behind our products from start to finish. Our customer service department is available Monday – Friday 8:30 AM – 5:30 PM Pacific Time and can help with assembly questions as well as, if necessary, replacing damaged or missing parts. To help expedite our service, please have these assembly instructions readily available, along with your order receipt.





CHECK BEFORE STARTING

Are you missing anything? Double-check all parts, hardware and accessories listed are all acccounted for.	Check out our Quick Tips! We recommend reviewing the pre-assembly handouts. Even experts need a refresher now and then!
Should we send any replacements? Are there any irregularities or flaws in the parts? We can send replacements!	Prep Time! Please review the assembly instructions and all diagrams prior to assembling.

PRE ASSEMBLY INTRODUCTION

We understand building ready-to-assemble furniture can be a challenging experience for some. To help avoid confusion, we have provided some helpful tips that may speed up the process.





Teamwork

ALWAYS have at least two people to help with transporting and assembling the product to avoid potential injury and/or damage.





Suitable Location

Assembling near the area of the intended location is highly recommended.





Sufficient Space

Make sure you have enough space to move around during the assembly.






Avoid Scratches

Use cardboard, blankets or a carpeted area while assembling furniture to prevent to prevent scratches and damages.





Flat Surface

Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.

ASSEMBLY AND CARE ADVICE




FAILURE TO FOLLOW THE GUIDELINES BELOW MAY RESULT IN INJURY AND/OR PROPERTY DAMAGE.



Position each part correctly and insert screws or bolts into their respective holes.



Use the appropriate hand tools or power tools for assembly. Select steps, such as tightening screws and/or bolts, may require hand tools to avoid causing damage during assembly.



Turn clockwise to tighten and only tighten when step is completed or when instructed to do so.



Save the instructions and store any supplied tools for later maintenance.



After two weeks, check and tighten any loose hardware and repeat again every six months thereafter.

IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.

3 PC COUNTER HEIGHT. DINING SET

SL3401-PT-3PK



- Please keep instructions for future reference.
- Check the quantity and irregularity of parts and hardware before you start.



PARTS

1

2

3







CUSHION SEAT 2 pcs.

LEFT STOOL LEG 4 pcs. RIGHT STOOL LEG

4 pcs.

4

5


6




STOOL SIDE STRETCHER 4 pcs. STOOL FRONT & BACK STRETCHER 4 pcs.

TABLE TOP 1 pc.

10




SIDE PANEL + **BACK PANEL** 1 pc.



8


LEFT BACK LEG 1 pc.



9


RIGHT BACK LEG 1 pc.

LEFT FRONT LEG 1 pc.



11

RIGHT FRONT LEG 1 pc.



12


CENTER STRETCHER 1 pc.

13




BACK STRETCHER 1 pc.

14



SHELF 2 pcs. 15



BOTTOM PANEL 1 pc.

STOOL HARDWARE

A



BOLT Ø1/4" x 2" 8 pcs.

D



SCREW 45mm 16 pcs. В



SPRING WASHER Ø1/4" 8 pcs.

Ε



ALLEN WRENCH M4 1 pc. C



FLAT WASHER Ø1/4" 8 pcs.

TABLE HARDWARE

F



BOLT Ø1/4" x 1-3/8" 11 pcs.



FLAT WASHER Ø1/4" 19 pcs.



ALLEN WRENCH M4 1 pc. G



BOLT Ø1/4" x 2-1/4" 8 pcs.

J



SCREW #8 x 2" 3 pcs. _



SPRING WASHER Ø1/4" 19 pcs.

K



SHELF PIN 8 pcs.

Carton	Disignation	Part			
	CUSHION SEAT	1			A x 8pcs
	LEFT STOOL LEG	2	٠		B x 8pcs
	RIGHT STOOL LEG	3	·		C x 8pcs
	STOOL SIDE	4	₹	Dittitititi	D x 16pcs
	STRETCHER				E x 1pc
	STOOL FRONT & BACK STRETCHER	5	₹	(a)	F x 11pcs
	TABLE TOP	6		0	G x 8pcs
	SIDE PANEL + BACK PANEL	7			H x 19pcs
SL3401-PT-3PK					I x 19pcs
	LEFT BACK LEG	8		Diminimo	J x 3pcs
	RIGHT BACK LEG	9			K x 8pcs
	LEFT FRONT LEG	10			L x 1pc
	RIGHT FRONT LEG	11			
	CENTER STRETCHER	12			
	BACK STRETCHER	13			
	SHELF	14			
	BOTTOM PANEL	15			

DO NOT FULLY TIGHTEN ALL BOLTS UNTIL ASSEMBLY IS COMPLETED. Part 1 x1pc Part 2 x2pcs Part 3 x2pcs Part 4 x2pcs Align legs (2,3) to the cushion seat (1). Part 5 x2pcs Postion the stretchers (4,5) onto the legs. Hardware A x4pcs Then secure legs onto the cushion seat (1) Hardware B x4pcs by using bolts (A) with washers (B,C). Hardware C x4pcs Hardware D x8pcs Hardware E x1pc 0 x 2 *~~* Flat head

Secure the stretchers (4,5) to the legs (2,3) by using screws (D.)

screw driver

2


Part 7 x1pc Part 15 x1pc


Hardware F x4pcs


Hardware H x4pcs


Hardware I x4pcs


Hardware L x1pc













ASSEMBLY COMPLETED



Please ensure the furniture rests on an even and flat surface. If the product wobbles or feels loose, double-check all bolts and/or screws are properly tightened and secured.

✓ Keep this handy!

Please retain this instruction manual and any order-related information for future reference.

Lift, don't drag!

To avoid damage to product please always LIFT the product when transporting of adjusting the placement.

This product is intended for RESIDENTIAL USE ONLY and not for commercial use.