

Use and care manual

Clean metal components with a very soft dry cloth. Under no circumstances should any metal polish be used, as its abrasive nature could damage the protective finish placed on the metal parts. Never wash glass shades in an automatic dishwasher. Instead, line a sink with a towel and fill with warm water and mild liquid soap. Wash glass with a soft cloth, rinse and wipe dry.