

## ASSEMBLY INSTRUCTIONS

MODEL #

FM3214-T

#### Questions?

GIVE US A CALL : 1-888-980-5122 MON-FRI 8:30AM - 5:30PM (PT)


#### **TOOLS REQUIRED**



Allen Wrench (Included)



2 - People



The Assembly Rating is a 5-point system showing the level of the effort needed to assemble a specific product.






Thank you for your purchase!

We hope you enjoy this new addition to your home for many years to come.

Our commitment to providing quality products does not simply end when you purchase our product. We fully stand behind our products from start to finish. Our customer service department is available Monday – Friday 8:30 AM – 5:30 PM Pacific Time and can help with assembly questions as well as, if necessary, replacing damaged or missing parts. To help expedite our service, please have these assembly instructions readily available, along with your order receipt.



## CHECK BEFORE STARTING

#### Are you missing anything?

Double-check all parts, hardware and accessories listed are all acccounted for.

#### Should we send any replacements?

Are there any irregularities or flaws in the parts? We can send replacements!



#### **Check out our Quick Tips!**

We recommend reviewing the pre-assembly handouts. Even experts need a refresher now and then!

#### **Prep Time!**

Please review the assembly instructions and all diagrams prior to assembling.

# PRE ASSEMBLY

We understand building ready-to-assemble furniture can be a challenging experience for some. To help avoid confusion, we have provided some helpful tips that may speed up the process.





#### Teamwork

ALWAYS have at least two people to help with transporting and assembling the product to avoid potential injury and/or damage.





#### **Suitable Location**

Assembling near the area of the intended location is highly recommended.





#### **Sufficient Space**

Make sure you have enough space to move aroung during the assembly.





#### Avoid Scratches

Use cardboard, blankets or a carpeted area while assembling furniture to prevent scratches and damages.

#### Flat Surface


Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.



## **ASSEMBLY** AND **CARE ADVICE**



FAILURE TO FOLLOW THE GUIDELINES BELOW MAY RESULT IN INJURY AND/OR PROPERTY DAMAGE.



Save the instruction and store any supplied tools for later maintenance.


After two weeks, check and tighten any loose hardware and repeat again every six months thereafter.

IT IS THE USER'S RESPONSIBILITY MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO WOOBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY USE SERIOUS INJURY.

## DINING TABLE FM3214-T • Please keep instructions for future reference. • Check the quantity and


Check the quantity and irregularity of parts and hardware before you start.


#### PARTS



(BALL SHAPE) (BALL SHAPE) 1pc.

### **ASSEMBLY INSTRUCTIONS**





2



This product is intended for RESIDENTIAL USE ONLY and not for commercial use.