

Sensonic Voice™ Controlled Smart Fan Best Practices

- Give your Sensonic Voice[™] Controlled Fan a unique name that does not contain the word "fan" or "light". Light and fan are commonly used in utterance for Alexa/Google to operate this product.
- Once connected to Alexa/Google, ensure that your preferred music streaming services are set up properly in their respective apps.
 - Spotify is not integrated with this product currently. If you would like to listen to music on Spotify, you must use a Bluetooth connection from your phone.
- Voice commands will prioritize the function of the light over the fan. See examples below.
- This product works like any Alexa Device. Common voice utterances using Master Bath as the fan's name:
 - "Alexa, turn Master Bath on."
 - This will turn on the light only.
 - "Alexa, turn on fan on Master Bath."
 - This will turn on both the fan and light.
 - "Alexa, turn off Master Bath."
 - This will turn off the light only.
 - The fan and light are independently controlled when already turned on.
 - "Alexa, play my music."
 - You can stream music through your preferred streaming service.
 - "Alexa, change Master Bath light to Soft White."
 - Refer to Quickstart Guide for other color options.
 - "Alexa, change Master Bath brightness to 50%."
 - Brightness and speaker volume can both be controlled by percentages.





Broan-NuTone LLC Hartford, Wisconsin 53027 800-558-1711 | Broan-NuTone.com

©2022 Broan-NuTone LLC | Printed in U.S.A. 99851153A | 11/22

