Item Number: A04458

WARNING (To reduce the risk of fire, electric shock, or personal injury):

- 1. We suggest installation by a **licensed electrician**.
- 2. Please read the instruction carefully and save it as you may need it at a later time.
- 3. Before you start, **NEVER** attempt any work without shutting off the electricity until the work is done.
 - » Go to the main fuse, or circuit breaker, box in your home.
 - Place the main power switch in the "**OFF**" position.
 - » Place the wall switch in the "OFF" position.
- 4. Mounting surface should be clean, dry, flat, strong enough and 1/4" larger than the canopy on all sides. Any gaps between the mounting surface and canopy exceeding 3/16" should be corrected as required.
- 5. Make sure that the ceiling or wall can stand the weight of the lamp before installation.
- 6. Make sure the voltage you are using is **120V**. The maximum wattage is **40W** per bulb.
- 7. Keep the lamp away from acidic and alkaline substances in case of damaging the surface of the lamp.
- 8. When replacing bulbs, you should turn off or unplug the lamp and you must wait until it is cool as bulbs get hot quickly.
- 9. The safety instructions appearing in this manual are not meant to cover all possible conditions that may occur. It must be understood that common sense, caution and care must be used with any electrical products.

IMAGE FOR FINISHED PRODUCT:

0

TOOLS REQUIRED (NOT INCLUDED):

Before starting assembly and installation please prepare the needed tools as below picture


Derore starting a	ssembly and instana	tion please prep		ois as below picture
				Change Constant
Ladder	Phillips head.flat blade screwdriver	Electrical tape	Pliers	Wire cutter/Stripper
PARTS TYPI (A) Mounting (B) Green gro (E) Canopy ((F) Strain reli (G) Ball knob (H) Cord (1) (I) Socket (1 (J) Screw (3) (K) Glass sha ACCESSOR (C) Plastic W (D) Mounting (L) Allen wrer ASSEMBLY & I 1. Carefully remo check that all p as shown in th 2. Turn off power Before you sta any work without the work is do » Go to the m Place the m » Place the w	blade screwdriver E & QTY INCLUDING: plate assembly (1) pund screw (1) 1) ief (1) (2)) ade (1) IES & QTY ENCLOSE ire Connector (3) screw (2) nch (1) INSTALLATION INS ove the fixture from the parts and accessories the above illustration. The installation, NE out shutting off the elements	D: STRUCTIONS: The carton and s are included EVER attempt Iectricity until rer, box in your hon " OFF " position. osition. (E) then		Wire cutter/Stripper
				——-G
	1	www.ihomeandel.co	om	Page: - 2 - / 4

www.ihomeangel.com

- 4 » Adjust the length of cord (H) to achieve the desired height of the mounted fixture.
 - 1) Use Allen wrench (L) to unscrew the screw in strain relief (F), carefully pull and push cord (H) through canopy (E) and strain relief (F) to lengthen or shorten the length of cord (H).
 - 2) Once the desired height of fixture is achieved, carefully tighten the screw till snug.

NOTE: To prevent cord (H) from slipping out of canopy (E), make an overhand knot of cord (H).


5 » If needed, shorten the extra length of the fixture wires from cord (H) so that they all are at least 6 inches (152.4 mm) long above canopy (E) within the outlet box.



6 » Carefully pass supply wires through mounting plate assembly (A).

Secure mounting plate assembly (A) to the outlet box with mounting screws (D).


NOTE: the side of mounting plate (A) marked "GND" must face out.



7 » Make wire connections

Connect wires as below wires connection shown. REFER TO THE FOLLOWING CHARTS, NEVER CONNECT OTHER WIRES TO GROUND WIRES.

Connect ground wires according to the below chart



Connect wires according to the below chart

Connect Black or Red Supply Wire to:	Connect White Supply Wire to:	
Black	White	
*Parallel cord (round & smooth)	*Parallel cord (square & ridged)	
Clear, Brown, Gold or Black without tracer	Clear, Brown, Gold or Black with tracer	
Insulated wire (other than green) with copper conductor	Insulated wire (other than green) with silver conductor	
Note: When parallel wires (SPT I & S re used. The neutral wire is square s r ridged and the other wire will be re hape or smooth (see illus.)	shaped	

www.ihomeangel.com

Page: - 3 - / 4

Twist wires together with plastic wire connector (C) until tightly joined, and wrap each connector with approved electrical tape for a more secure connection, then carefully tuck all wires into the outlet box.

8 » Fix canopy (E) to mounting plate assembly (A) and secure with the previously removed ball knobs (G).

Note: canopy (E) should be snug against the ceiling and ball knobs (G).

If not, adjust the threaded length of the pre-assembled mounting screws on mounting plate assembly (A) by unscrewing the pre-assembled hex nuts and then screwing the mounting screws in or out of mounting plate (A) until the secure length is achieved.

Tighten the hex nuts and back to step 8.

- 9 » 1) Remove screws (J) from socket (I). Carefully place glass shade (K) on socket (I), then secure it with screws (J).
 - 2) Install the bulb (Not included) (Please do not exceed the maximum wattage recommended on the socket.)

E (`t

CEILING

10. Check everything is already installed properly, then you could turn on the light. Enjoy!

ORDERING PARTS

Keep this sheet for future reference in case you need to order replacement parts. All parts for this fixture can be ordered from the place of purchase. ordering parts.

CLEANING

To clean, wipe the fixture with a soft cloth. Clean glass with a mild cleaner (such as mild and nonabrasive soap). Do not use abrasive materials such Be sure to use exact wording from illustration when as scouring pads or powders, steel wool or abrasive paper.

K