



Before You Start

- ⚠ Please read all instructions carefully.
- ⚠ Retain instructions for future reference.
- ⚠ Separate and count all parts and hardware.
- ⚠ Read through each step carefully and follow the proper order.
- ⚠ We recommend that, where possible, all items are assembled near to the area in which they will be placed in use, to avoid moving the product unnecessarily once assembled.
- ⚠ Always place the product on a flat, steady and stable surface.
- ⚠ Keep all small parts and packaging materials for this product away from babies and children as they potentially pose a serious choking hazard.



Vor dem Beginnen

- ⚠ Bitte lesen Sie alle Anweisungen sorgfältig durch.
- ⚠ Bewahren Sie die Anweisungen zum zukünftigen Verwendung auf.
- ⚠ Überprüfen Sie, ob alle Teile und Zubehörteile vorhanden sind.
- ⚠ Lesen Sie jeden Schritt sorgfältig durch und befolgen Sie die richtige Reihenfolge.
- ⚠ Wir empfehlen, alle Teile möglichst in der Nähe des Aufstellungsortes zu montieren, um unnötige Bewegungen nach der Montage zu vermeiden.
- ⚠ Stellen Sie den Artikel immer auf eine ebene, feste und stabile Fläche.
- ⚠ Halten Sie alle kleinen Teile und Verpackungsmaterialien fern von Babys und Kindern, ansonsten besteht Erstickungsgefahr.



Avant de Commencer

- ⚠ Veuillez lire attentivement toutes les instructions.
- ⚠ Conservez les instructions pour vous y référer ultérieurement.
- ⚠ Vérifiez toutes les pièces et les accessoires.
- ⚠ Lisez attentivement chaque étape et suivez l'ordre correct.
- ⚠ Nous recommandons que, dans la mesure du possible, tous les produits soient assemblés à proximité de la zone où ils seront utilisés, afin d'éviter tout déplacement inutile du produit une fois assemblé.
- ⚠ Placez toujours le produit sur une surface plane et stable.
- ⚠ Conservez toutes les petites pièces de ce produit et les matériaux d'emballage hors de portée des bébés et des enfants, car ils pourraient présenter un risque d'étouffement.



Antes de Empezar

- ⚠ Lea atentamente todas las instrucciones.
- ⚠ Conserve las instrucciones para futuras consultas.
- ⚠ Separe y cuente todas las piezas y los accesorios.
- ⚠ Lea detenidamente cada paso y siga el orden correcto.
- ⚠ Recomendamos que, siempre que sea posible, todos los elementos se monten cerca de la zona en la que se van a utilizar, para evitar mover el producto innecesariamente una vez montado.
- ⚠ Coloque siempre el producto sobre una superficie plana, estable y firme.
- ⚠ Mantenga todas las piezas pequeñas y los materiales de embalaje de este producto lejos de los bebés y los niños, ya que pueden representar un grave riesgo de asfixia.

Product Specifications:

SIZE (AT BASE): 10 x 20 ft/3 x 6 m	CANOPY FRAME: Powder-Coated Metal
SIZE (Canopy Top): 10 x 20 ft/3 x 6 m	TOP CLOTH FABRIC: Oxford polyester fiber with an upgraded silver-plated PU lining
SHADED AREA: 200 sq.ft./18 m ²	PACKLIST: 1. Canopy top x 1 2. Canopy frame x 1 3. Portable bag x 1 4. Tent stakes x 12 & ropes x 6 5. Instruction manual x 1
CARRY BAG SIZE: 47.2" x 8.7" x 15.7" /120 x 26 x 40 cm	
CANOPY SIZE: 46.9" x 8.7" x 15" /120 x 26 x 38 cm	
PACKAGE WEIGHT: 60 lbs/30kg	

THE LATEST TECHNOLOGY IN THE INDUSTRY:

1. Double-line sewing and reinforced stress sewing prevent water penetration from seams, making it 100% waterproof.
2. The pop-up tent includes waterproof sealing tape to prevent water from pooling in wet conditions.
3. Roof raising design to prevent water accumulation.



Prima di Iniziare

- ⚠ Si prega di leggere attentamente tutte le istruzioni.
- ⚠ Conservare le istruzioni per riferimento futuro.
- ⚠ Separare e contare tutte le parti e gli accessori.
- ⚠ Leggere attentamente ogni passo e seguire l'ordine corretto.
- ⚠ Si consiglia, ove possibile, di assemblare tutti gli articoli vicino alla zona in cui verranno posti in uso, per evitare di spostare inutilmente il prodotto una volta assemblato.
- ⚠ Posizionare sempre il prodotto su una superficie piana, stabile.
- ⚠ Tenere tutte le piccole parti e i materiali di imballaggio di questo prodotto lontano dalla portata di neonati e bambini, in quanto possono costituire un serio pericolo di soffocamento.



Zanim Zacznieś

- ⚠ Zapoznaj się z instrukcją.
- ⚠ Zachowaj instrukcję do wglądu.
- ⚠ Posortuj części i upewnij się, że zestaw jest kompletny.
- ⚠ Zapoznaj się ze sposobem montażu i postępuj zgodnie z instrukcją.
- ⚠ Zalecamy, aby montaż odbywał się możliwie najbliżej miejsca docelowego położenia produktu, aby uniknąć niepotrzebnego przesuwania.
- ⚠ Upewnij się, że produkt znajduje się na płaskiej i stabilnej po wierzchni.
- ⚠ Upewnij się, że materiały wykorzystane podczas pakowania produktu oraz jego elementy znajdują się poza zasięgiem dzieci, gdyż stwarzają potencjalne ryzyko zadławienia.

CAUTION:

1. When adjusting the height, please place your fingers above the button to avoid getting stuck during setup and takedown.
2. Do not set up the canopy in rainy or windy weather.
3. In unattended situations and in bad weather, the tent should be taken down. This product is not intended to withstand extreme/high winds or bad weather.
4. Do not use fire near the gazebo or place it near a heat source.
5. Do not install the gazebo on uneven ground.
6. When installing the gazebo, you need to ensure that the frame is locked and that the tent is properly secured with a heavy object.
7. There are 6 wind rope buckles for binding wind ropes and wind rope nails to fix the tent and increase stability.
8. Foot pads with ground nail holes: ensure that it is firmly fixed on the ground when in use.
9. Rope and ground stakes add stability.
10. Attach the canopy top cloth and sidewalls to the legs with hook and loop fasteners. Each wall has hook and loop fasteners or straps with buckles to fix the wall to the leg making it tight and secure enough.

TIPS:



STORAGE:

Before storing the canopy, make sure that the parts are not wet or damp to prevent mold.



CLEANING:

Clean the canopy with mild detergent and water.



INSTALLATION:

Do not open the gazebo roughly. Improper force may result in damage to the parts or connectors.




MAINTENANCE:

When not in use, this product should be kept closed and stored away to avoid potential damage.

HOW TO SET UP:

It is recommended that two or more people complete the installation of the pop-up canopy tent.

Follow these instructions and be careful to avoid getting your fingers caught in any moving parts when opening and closing the frame.




Step 1: Pull out the canopy frame:

- Place the canopy frame in the center of the area that needs shade.
- With your partner on the other side of the frame, grab both outer legs and lift the frame slightly off the ground. Then pull the frame back so that it opens to 3/4 of its full opening size. Finally, place the frame back on the ground.

NOTE: Do not open the violently; improper force may cause damage to the brackets or connectors.

Step 2: Attaching the pop-up canopy top:


- Unfold the pop-up canopy top and place it on top of the pop-up canopy frame.
- Secure the pop-up canopy top to the corners of the canopy frame using the hook and loop fasteners.



If the cloth does not seem to fit, you need to adjust the degree of opening of the tent frame.

Step 3: Locking the frame:

- At this point, stand with a partner on the opposite side of the frame and grab the outside bar. Pull it back until the shelter is fully open.
- Then push upward with one hand while holding the top of the leg with the other hand to engage the slider at each corner. Repeat this procedure on the other legs.
- Lift all the corners upward until they click, and the snap goes into the positioning hole.




Step 4: Adjust the canopy height:

Press the red button on each leg and push the leg up or down to adjust the height of the gazebo (3 heights available).



Step 5: Secure the canopy in place:

- A. There are 6 rope loops at the corners of the roof for tying weatherproof ropes to secure the tent. Tie the ropes to the rings, straighten the ropes, tie a stake to the other end of the rope, and then insert the stake into the ground.
- B. Insert ground stakes through the footings with stake holes into the soil/ground to hold the canopy in place.
- C. Ropes and ground nails provide added stability.



How To Take Down

Step 1:

Unfasten the hook and loop fasteners and detach the canopy top tarpaulin. Fold the canopy top tarpaulin neatly.

Step 2:

Remove the stakes and lower the tent height.

Step 3:

Unlock the frame.

Step 4:

Fold the frame.

Step 5:

Place the frame and the canopy back into the portable bag.

TIPS: Before storing the canopy, ensure that the parts are dry to prevent mold. Place all the parts in the roller bag for storage.