
MOUNTING&WIRING

WARNING:

Improper Installation may cause electrical shock, fire,or equipment damage. The person performing the Installation must be familiar with the construction and operation of the product and associated hazards



Wire Connection Diagram:




Please proceed in an alphabetical order:

A.Existing Elextrical BOX B.Greecher G.Greecher Scrows
D.Greend Wire E.Ganopy F.Wire G.Junction Cape
attach the croscher(Bite the existing electrical box(A)
using the two croscher scrows(C)which are not supplied
and should already in your box. Pace the main wire(F)and
ground wire(D)through the canopy(E)and the
croscher(B)until the end of the main wire(F)reaches the

(A)where you can wire use electrician connections. Be sure when connecting the wire use electrician approved junction cape(G).stow the excess wire in the electrical beat(A).raise the canopy(E),attach canopy(E)to ceiling,and hold the canopy(E).

DIMENSION



PART LIST INSTALLATION&MOUNTING INSTRUCTIONS 1 2 3 1 NO COMPONENT QUANTITY 2 Please adjust cable length according to the height of the ceiling 4 NO **5** DIMMABLE:fully dimmable with compatible dimmer switch to create the perfect atmosphere Type of Light Source: incandescent,LED or CFL COMPONENT Bulbs.Bulb base E12,60 watts maximum(not included) 90 80 QUANTITY E12