Stack Chair

Assembly Instructions-one piece

A045-001-001/A045-002-001



KINDLY NOTICE- Please read these instructions carefully before starting assembly

HASSEL-FREE WARRANTY

We proudly provid 1-YEAR warranty, if there is any questions with the products, please feel free to contact with us.

Email: support@patio-outdoor.com




The assembly will be easier with 2 people while 1 person could also do the job.



Around 10 MIN ASSEMBLY

Parts List

Note: All parts of the screws should not be completely tightened the first time please tighten all screws after all parts are installed.




A 2PCS	B 2PCS	C 1PCS	D 1PCS	
M6x55	M6x70	Φ6	M6	الک M6
AA 4PCS	BB 4PCS	CC 8PCS	DD 8PCS	EE 8PCS
	5			
FF 1PCS	GG 1PCS			

Assembly

Note: All parts of the screws should not be completely tightened the first time please tighten all screws after all parts are installed.

Step1


Assemble A and B according to the illustration. Note: Combined D and E to make stable screws




Tighten all screws and Place F on top of it.




Align the holes and insert the screws to fasten the installing B and C.



Adjust each screw to make the chair flat and stable.







Outdoor furniture 1-year Warranty Program For a period of one (1) years after date of purchase, the Manufacturer will either repair or replace defective components in accordance with this Limited Warranty. This warranty is between the Manufacturer and the original purchaser and is valid only when accompanied by the original purchaser's sales receipt showing original date of purchase

The manufacturer or its authorized dealer can accept or reject warranty claims based on its findings. This warranty applies in normal residential use only and is not intended for commercial use. The Manufacturer can make substitutions as required of materials, components, and sub-components of comparable value and utility. This warranty is limited to product repair or replacement (to be determined solely by the Manufacturer). Warranty return is limited to only the single affected component.

This limited warranty covers only manufacturing defects and does not cover normal wear and tear, damage due to acts of nature (such as, but not limited to freezing or high winds), abuse or misuse, including chemical damage from suntan oil or other chemicals, exposure to extreme heat or cold, abrasion or excessive weight. This product is intended to be used in standard installations only. This warranty is voidif the product is not used for its intended purpose. The Manufacturer disclaims liability for any aspect of installation and any inconvenience caused by a defective part of a component

Certain items are not covered by this warranty. These include, but are not limited to the following:

- 1. Components subjected to abuse, including abuse intended to simulate failure
- 2. Damages caused by retailer, shipper or installation error (such as scratches, dents, tears, chips, etc.)
- 3. Any part that only shows normal wear and tear on the surface, including debris, scratches, or material stretching and stitching.
- 4. Tears, punctures, scratches or any damage caused by improper installation or use.

General care & maintenance

Only clean using a damp cloth and mild detergent, do no use bleach or abrasive cleaners.

* If you need after-sales service, please provide the original purchase record and a brief description of the problem. Please also provide your email address or mobile number