


EXPLODED VIEW & PARTS – PPCK1

PPU260



NO	PART NAME	QTY	PART #
1	SCREW M5x14	3	20061124
2	STARTER ASSEMBLY	1	20085784
3	STARTER COVER	1	20058406
4	EYELET	1	20058286
5	START ROPE	1	20056239
6	START GRIP	1	20056981
7	COIL SPRING	1	20058403
8	START PULLEY	1	20073654
9	SPRING START	1	20058404
10	RATCHET WHEEL	1	20073656
11	PLATE WASHER	1	20061446
12	ST SCREW 4.8x16	1	20054544
13	START REEL	1	20058339
14	WASHER 8	1	20061431
15	OIL-SEAL 12x22x7	1	20088073
16	CRANK CASE RH SIDE	1	20053624
17	GASKET / CRANK CASE	1	20050962
18	BEARING 6001	2	20061607
19	CRANK SHAFT ASSEMBLY	1	20089389
20	KEY 3x3.5x10	1	20054650
21	BEARING 6001 8x11x11	1	20062683
22	CIRCLIP / PISTON PIN	2	20053071
23	PISTON PIN	1	20053538
24	PISTON	1	20073628
25	PISTON RING	2	20053537
26	GASKET / CYLINDER	1	20050958
27	CYLINDER	1	20089390
28	SCREW M5x20	4	20054550
29	SPARK PLUG	1	20079314
30	ST SCREW 4.2x8	2	20051786
31	CYLINDER HEAD INSULATION PLATE	1	20050984
32	ST SCREW 4.2x10	2	20051790
33	WIND DEFLECTOR	1	20050983
34	ST SCREW 4.8x16	1	20054544
35	TOP HOUSING	1	20078282
36	IGNITION WIRES	1	20050977
37	SPARK PLUG CAP	1	
38	IGNITION	1	
39	SCREW M5x20	2	20054550
40	PIN ϕ 5x10	2	20054566
41	CRANK CASE LH SIDE	1	20053621
42	SCREW M5x25	3	20061082
43	OIL-SEAL 12x22x7	1	20088073
44	FLYWHEEL ASSEMBLY	1	20050980
45	FLANGE NUT M8x1	1	20054557
46	FLAT WASHER	2	20062670
47	CLUTCH ASSEMBLY	1	20070201
48	SADDLE ELASTIC WASHER 8	2	20062669
49	BOLT / CLUTCH	2	20062668
50	PIN ϕ 4x10	2	20061561
51	FAN COVER	1	20053632
52	SCREW M5x20	4	20054550
53	CLUTCH DRUM ASSEMBLY	1	20058343
54	CIRCLIP 35	1	20054564
55	BEARING 6202	1	20061639
56	CIRCLIP 15	1	20061548
57	CLUTCH DRUM HOUSING	1	20053642
58	SCREW M6x20	4	20061120

59	SHOCK ABSORBER SLEEVE	1	20070321
60	CLAMP RH	1	20070323
61	CLAMP LH	1	20070322
62	SCREW M5x25	2	20061082
63	SCREW M5x12	1	20061111
64	SCREW M5x55	2	20061109
65	MUFFLER COVER	1	20058419
66	LIMIT RETAINING RING	2	20050001
67	MUFFLER	1	20092691
68	MUFFLER INSULATION PAD	1	20050985
69	GASKET / MUFFLER	1	20050960
70	SCREW M4x12	2	20061121
71	GASKET	1	20050974
72	ADMITTING PIPE	1	20052517
73	THROTTLE LINE PLATE	1	20050247
74	SCREW M4x6	1	20051738
75	SCREW M5x20	2	20054550
76	GASKET / CARBURETOR	1	20050971
77	CARBURETOR	1	20088090
78	AIR FILTER ASSEMBLY	1	
79	AIR FILTER BASE	1	20067455
80	SCREW M5x45	2	20061126
81	SPONGE	1	20058398
82	FUEL CAP	1	20067463
83	FUEL TANK COVER	1	20058996
84	SEALING GASKET	1	20070351
85	ANTI-DROP PLATE	1	20059012
86	FUEL TANK	1	20058401
87	RUBBER LINING	4	20070345
88	FUEL TANK HOUSING	1	20058394
89	SCREW M5x25	4	20061082
90	BALANCER	1	20054685
91	AIR TUBE (40mm)	1	20055779
92	FUEL TUBE (150mm)	1	20055779
93	RETURN TUBE (85mm)	1	20054576
94	RETAINER FUEL TUBE	1	20070348
95	TUBING CIRCLIP	1	20054663
96	FUEL FILTER	1	20053113
97	SPARK CATCHING NET	1	20076422
98	SPARK TRAP NET RETENTION SLEEVE	1	20076421
99	SCREW ST4x8	1	20085878
100	NUT M5	4	20054558
101	PLASTIC HANDLE / LH	1	20070376
102	SPRING / TRIGGER	1	20059139
103	WIRE CABLE A	1	20050443
104	WIRE CABLE B	1	
105	WIRE TUBE	1	
106	THROTTLE CABLE ASSEMBLY	1	20050254
107	PLASTIC HANDLE / RH	1	20070377
108	SCREW M5x14	2	20060983
109	ST SCREW 3.5x9.5	2	20051727
110	ST SCREW ST4x12	2	20051796
111	SCREW M5x14	2	20060983
112	TRIGGER	1	20059161
113	IGNITION SWITCH	1	20050697
114	LOCK TRIGGER	1	20059147
115	SPRING / TRIGGER	1	20059140
116	RUBBER HANDLE	1	20072569
117	SLEEVE 26	1	20058676


NO	PART NAME	QTY	PART #
118	CLAMP	1	20058681
119	NUT M5	1	20054558
120	SCREW M5x22	1	20061081
121	HARNESS CLAMP ASSEMBLY	1	20058685
122	BACK SHAFT ASSEMBLY	1	20077191
123	BACK AL TUBING	1	20050259
124	TRANSMISSION SHAFT	1	20054026
125	RUBBER / SHAFT	3	20072574
126	CONNECTOR ASSEMBLY	1	20070365
127	SCREW M5x25	1	20061082
128	SCREW M5x12	1	20061111
129	SCREW M6x50	1	20061322
130	PLATE WASHER 6	1	20061506
131	LOCK KNOB	1	20059127
132	NUT M6	1	20061361
133	FRONT HANDLE	1	20059130
134	NUT M5	2	20054558
135	HANDLE BASE	1	20059132
136	CLAMP	1	20059134
137	BAR	1	20059136
138	SCREW M5x28	2	20060874
139	PLATE WASHER $\Phi 5 \times 12 \times 1.5$	3	20061445
140	PLATE WASHER $\Phi 5 \times 12 \times 1.5$	1	20061446
141	ST SCREW 5x19	2	20060977

ASSEMBLIES – PPU260


QTY	DESCRIPTION	PART NUMBER	ASSY PART NUMBER	ASSY DESCRIPTION
4	RUBBER LINING	20070345	68821701	FUEL TANK BASE ASSEMBLY
1	FUEL TANK HOUSING	20058394		
4	SCREW M5x25	20061082		
1	FUEL CAP	20058996	20072561	FUEL TANK CAP ASSEMBLY
1	GASKET RUBBER	20070351		
1	ANTI-DROP BOARD	20059012		
3	SCREW M5x14	20061124	68821702	STARTER ASSEMBLY
1	STARTER COVER	20058406		
1	EYELET	20058286		
1	STARTER ROPE	20056239		
1	STARTER GRIP	20056981		
1	COIL SPRING	20058403		
1	START PULLEY	20073654		
1	SPRING START	20058404		
1	RATCHET WHEEL	20073656		
1	PLATE WASHER	20061446		
1	ST SCREW 4.8x16	20054544		
1	START ROPE	20056239		
1	START GRIP	20056981	68821703	STARTER GRIP AND ROPE ASSEMBLY
1	IGNITION WIRE		20050977	IGNITION ASSEMBLY
1	SPARK PLUG CAP			
1	IGNITION			
1	CARBURETOR	20088090	68821705	CARBURETOR ASSEMBLY
1	GASKET / CARBURETOR	20050971		
2	NUT M5	20054558	20072570	FRONT LOOP HANDLE AND BAR ASSEMBLY
1	FRONT HANDLE	20059130		
1	PLATE WASHER $\Phi 5 \times 11 \times 2$	20061446		
2	ST SCREW 4.8x19	20060977		
1	HANDLE BASE	20059132		
1	CLAMP	20059134		
1	BAR	20059136		
2	SCREW M5x28	20060874		
3	PLATE WASHER $\Phi 5 \times 12 \times 1.5$	20061445		
1	SLEEVE 26	20058676	68821706	HARNESS CLAMP ASSEMBLY
1	CLAMP	20058681		
1	NUT M5	20054558		
1	SCREW M5x22	20061081		
1	HARNESS CLAMP ASSEMBLY	20058685		
1	BALANCER	20054685	20085776	FUEL FILTER ASSEMBLY
1	AIR TUBE	20055779		
1	FUEL TUBE	20055779		
1	RETURN TUBE	20054576		
1	RETAINER FUEL TUBE	20070348		
1	TUBING CIRCLIP	20054663		
1	FILTER FUEL	20053113		
1	AIR FILTER BASE	20067455	68821704	AIR FILTER HOUSING ASSEMBLY
2	SCREW M5x45	20061126		
1	AIR FILTER COVER	20067463		
1	FLANGE NUT M8x1	20054557	20092607	CLUTCH ASSEMBLY
2	FLAT WASHER	20062670		
1	CLUTCH ASSEMBLY	20070201		
2	SADDLE ELASTIC WASHER 8	20062669		
2	BOLT / CLUTCH	20062668		
2	SCREW M5x55	20061109	20092608	MUFFLER ASSEMBLY
1	MUFFLER COVER	20058419		
2	LIMIT RINGS	20050001		
1	MUFFLER	20092691		
1	MUFFLER INSULATION PAD	20050985		
1	GASKET/ MUFFLER	20050960	20092604	ADMITTING PIPE ASSEMBLY
1	GASKET	20050974		

1	ADMITTING PIPE			
---	----------------	--	--	--


PPA100




NO	PART NAME	QTY	PART #
1	RUBBER SLEEVE	3	20072574
2	FRONT ALUMINUM TUBE	1	20088461
3	DRIVE SHAFT	1	20054026
4	LIMIT SLEEVE	1	20070363
5	SCREW M6x25	1	20061116
6	SCREW M6x12	1	20061115
7	GEAR BOX ASSEMBLY	1	20070354
8	STRING HEAD ASSEMBLY	1	30001285
9	PROTECTIVE COVER	1	20067951
10	ST SCREW 4.8x13	2	20054547
11	CUTTING BLADE	1	20059120
12	GUARD	1	20067954
13	CONNECTING PLATE	1	20059117
14	SCREW M6x20	2	20062718

PPA500

NO	PART NAME	QTY	PART #
1	DRIVE SHAFT	1	20054026
2	LIMIT SLEEVE	1	20070363
3	RUBBER SLEEVE	3	20072574
4	FRONT ALUMINUM TUBE	1	20088461
5	POLE PRUNER	1	20070179
6	SCREW M5x12	1	20061111
7	SCREW M5x25	1	20061082
8	SAW CHAIN	1	30001944
9	GUIDE BAR (OREGON)	1	30001374

PPA600

NO	PART NAME	QTY	PART #
1	TRANSMISSION SHAFT	1	20054026
2	LIMIT SLEEVE	1	20070363
3	RUBBER SLEEVE PARTS	3	20072574
3-1	BEARINGS 14x14x8	3	20059115
3-2	RUBBER SLEEVES	3	20070352
4	FRONT ALUMINUM TUBE	1	20088461
5	HEDGE TRIMMER ASSEMBLY	1	20070189
6	SCREW M5x12	1	20061111
7	SCREW M5x25	1	20061082

PPA700

NO	PART NAME	QTY	PART #
24	BLADE UPPER PLATE	1	20059123
25	LOWER PROTECTIVE COVER	1	20059124
26	FLANGE NUT M10x1.25	1	20055871
63	BLADE	1	20070304