

MODEL #DS-11692A


Use and Care Guide

HOSE POT

Operation

1 Using the hose pot

- ☐ Always place the hose pot on a hard, level surface.
- ☐ Hold vertically pillar and push into space provided in pot.
- ☐ Connect the hose to the spigot through the side hole before coiling the hose.
- ☐ Wind the hose around the pillar hidden inside the pot.



Safety Information

This product is suitable for both indoor and outdoor use.



WARNING: Do not drink directly from the watering can as it is not food or beverage safe.



WARNING: Keep your product out of rain.



WARNING: Keep out of reach of children and pets.



WARNING: Keep your hose inside the bowl when not in use.

Care and Cleaning

Clean with a soft cloth, mild soap and water or a dust cloth. Do not use a scrub brush. If the paint chips, use paints and a brush to fix. If rust is showing, sand lightly and repaint the area with paints.

Warranty

This product carries no warranty.

For questions or concerns about this product, contact the Customer Service Team 8:00 a.m. to 5:00 p.m. EST at 1-866-397-9312 or E-mail: customerservice@dewansons.com.