

ASSEMBLY INSTRUCTIONS


MODEL#

FM3211-PC-2PK

Questions?

GIVE US A CALL: 1-888-980-5122 MON-FRI 8:30AM - 5:30PM (PT)

TOOLS REQUIRED





Screwdriver (Not included)



Allen Wrench (Included)



2 - People

ASSEMBLY RATING











EASY -

→ DIFFICULT

The Assembly Rating is a 5-point system showing the level of the effort needed to assemble a specific product.





Thank you for your purchase!

We hope you enjoy this new addition to your home for many years to come.

Our commitment to providing quality products does not simply end when you purchase our product. We fully stand behind our products from start to finish. Our customer service department is available Monday – Friday 8:30 AM – 5:30 PM Pacific Time and can help with assembly questions as well as, if necessary, replacing damaged or missing parts. To help expedite our service, please have these assembly instructions readily available, along with your order receipt.



Consumer Hotline Toll-Free 1-888-980-5122



WEBSITE www.foagroup.com



Monday to Friday 8:30AM- 5:30PM (PT)



E-MAIL cs.ec@foagroup.com









foagroup



FurnitureOfAmerica



	Are you missing anything?	Check out our Quick Tips!
	Double-check all parts, hardware and accessories listed are all acccounted for.	We recommend reviewing the pre-assembly handouts. Even experts need a refresher now and then!
Are there any	Should we send any replacements?	Prep Time!
	Are there any irregularities or flaws in the	Please review the assembly instructions and all diagrams prior to assembling.

PRE ASSEMBLY INSTRUCTION

We understand building ready-to-assemble furniture can be a challenging experience for some. To help avoid confusion, we have provided some helpful tips that may speed up the process.





Teamwork

ALWAYS have at least two people to help with transporting and assembling the product to avoid potential injury and/or damage.





Suitable Location

Assembling near the area of the intended location is highly recommended.





Sufficient Space

Make sure you have enough space to move aroung during the assembly.





Avoid Scratches

Use cardboard, blankets or a carpeted area while assembling furniture to prevent scratches and damages.





Flat Surface

Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.

ASSEMBLY AND CARE ADVICE



FAILURE TO FOLLOW THE GUIDELINES BELOW MAY RESULT IN INJURY AND/OR PROPERTY DAMAGE.



Position each part correctly, and insert screws or bolts into their respective holes.



Use the appropiate handtools or powertools for assembly. Select steps, such as tightrning screws and/or bolts, may require handtools to avoid causing damage during assembly.



Turn clockwise to tighten and only tighten when step is completed or when instructed to do so.



Save the instruction and store any supplied tools for later maintenance.



After two weeks, check and tighten any loose hardware and repeat again every six months thereafter.

IT IS THE USER'S RESPONSIBILITY MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO WOOBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY USE SERIOUS INJURY.


COUNTER HT STOOL FM3211-PC-2PK




- · Please keep instructions for future reference.
- Check the quantity and irregularity of parts and hardware before you start.



PARTS







SIDE FRAME (LEFT)


1pc. x2

SIDE FRAME (RIGHT) 1pc. x2

BOX FRAME 1pc. x2

5

6



FRONT & BACK RAIL 2pcs. x2



TOP REST 1pc. x2



CUSHION SEAT 1pc. x2


HARDWARE


В JCBC M6 x 70mm + S/W M6 ALLEN KEY M4 + F/W M6 x 13mm (BALL SHAPE) JCBC M6 x 25mm 4pcs. x2 4pcs. x2 1pc. D E F $\mathcal{K}_{\mathcal{IIIII}}$ PH SCREW M4 x 12mm L BRACKET FH SCREW #8 x 32mm 4pcs. x2 4pcs. x2 8pcs. x2 G WOOD DOWEL M8 x 25mm

2pcs. x2

ASSEMBLY INSTRUCTIONS


1 2






ASSEMBLY INSTRUCTIONS


5



6



7



Turn clockwise or anti-clockwise to adjust leg leveller.

ASSEMBLY COMPLETED



Please ensure the furniture rests on an even and flat surface. If the product woobles or feels loose, double-check all bolts and/or screws are properly tightened and secured.

Keep this handy!

Please retain this instruction manual and any order-related information for future reference.

Lift, don't drag!

To avoid damage to product please always LIFT the product when transporting of adjusting the placement.