












## Assembly Instructions, #20028 Double Hall Stand/ Sofa Table with Display Shelf




A: Top Assembly	
B: (4) Side Legs	
C: (2) Center Legs	
D: Shelf	
E: (12) Flat Washers	
F: (12) Lock Washers	
G: (12) Bolts	
H: Allen Wrench	
I: (6) Screws	
J: (4) Extra Drawer Glides	

## Assembly Steps

### Step 1

1.1 Put the table top upside down on a soft surface and remove drawers. Fasten two side legs and one center leg with parts (E & F & G) on the back of table side.


1.2 Reverse and fasten the knobs on outside of drawer front.



### Step 2


2.1 Lay the table on its back, insert the shelf on the leg notches, hold the shelf and fasten the center leg.

2.2 Fasten the remaining two side legs.



### Step 3

Put the table upside down, push the legs into the shelf and fasten shelf with six screws.



### Step 4

4.1 Place the table right side up and insert the drawer.

4.2 Fasten the anti-tipping hardware on the back of table into pre-drilled holes on the wall.

4.3 Adjust levelers on side legs if needed.

