




BEVERAGE REFRIGERATOR AND COOLER

User Guide



IVABC620SS
Holds 62 cans
Stainless steel

IVABC1010B
Holds 101 cans
Black

IVABC1010SS
Holds 101 cans
Stainless steel

IVABC1260B
Holds 126 cans
Black

IVABC1260SS
Holds 126 cans
Stainless steel

Thank you for purchasing the Ivation® Beverage Refrigerator and Cooler. This User Guide is intended to provide you with guidelines to ensure that operation of this product is safe and does not pose risk to the user. Any use that does not conform to the guidelines described in this User Guide may void the limited warranty.

Please read all directions carefully before using the product and retain this guide for reference. This product is intended for household use only. It is not intended for commercial use.

This product is covered by a limited one-year warranty. Coverage is subject to limits and exclusions. See warranty for details.

TABLE OF CONTENTS

- 3 SAFETY PRECAUTIONS**
- 4 PRODUCT OVERVIEW**
- 6 INSTRUCTIONS**
- 8 CARE**
- 9 SPECS**
- 10 TROUBLESHOOTING**
- 11 WARRANTY**
- 12 GET IN TOUCH!**


⚠ WARNING: Please read and understand all instructions before operating this appliance.

- **CHOKING HAZARD:** Small parts. This product contains small parts and is not suitable for children under 3 years old.
- Remove all packaging materials before using this product. Please keep all packaging materials out of reach of children and pets.
- Properly dispose of all packing materials immediately after unpacking product, as the bags used for packaging could present a suffocation or choking hazard.
- Read all instructions carefully before attempting to operate this device. Improper usage could result in injury or a reduction of efficacy in the product.
- Never allow children to operate, play with, or crawl inside the appliance.
- Keep all flammable liquids or materials away from this unit. Failure to do so may result in a fire or explosion.
- Keep product out of direct sunlight and away from heat sources.
- Use only with a properly grounded, standard 115 V 60 Hz electrical outlet to avoid the risk of electrical shock.
- Do not use an extension cord with this unit.
- Do not place any objects on top of the unit.
- If you are disposing an old unit, remove its door and leave shelves in place to avoid an entrapment hazard.


Model	Storage Capacity	Temperature Range
IVABC620SS	Holds 62 cans	38°F - 50°F (3°C - 10°C)
IVABC1010B	Holds 101 cans	38°F - 50°F (3°C - 10°C)
IVABC1010SS	Holds 101 cans	38°F - 50°F (3°C - 10°C)
IVABC1260B	Holds 126 cans	38°F - 50°F (3°C - 10°C)
IVABC1260SS	Holds 126 cans	38°F - 50°F (3°C - 10°C)

GET TO KNOW YOUR WINE COOLER


- ❶ Cooler exterior
- ❷ Shelves
- ❸ Retainer bar
- ❹ Feet
- ❺ Upper door hinge with cover
- ❻ Glass door
- ❼ Integrated door handle
- ❽ Door gasket
- ❾ Temperature control
- ❿ Bottom hinge



IVABC1010B/IVABC1010SS




IVABC1260B/IVABC1260SS



SETUP INSTRUCTIONS

- Place the unit on a flat, level surface that can support the weight of a fully loaded cooler.
- Before plugging in the cooler, let it stand upright for three (3) hours.
- Position the cooler in a dry, well-ventilated space between 41°F - 90°F (5°C - 32°C).
- Leave a space of at least 6" in the back of the unit and 10" on both sides.

SETTING THE TEMPERATURE CONTROL



- After 24 to 48 hours, adjust the temperature control to the setting that best suits you. (Note that temperature settings of “3” and “4” are recommended for home and office use.)
- To turn off the appliance, turn the temperature to “0”.
NOTE: Turning the temperature control to “0” stops the cooling cycle, but does not fully shut down the unit. If the unit is unplugged, loses power, or turns off, you must wait three to five (3 - 5) minutes before restarting the unit.


Proper Operating/Energy-saving Tips:

- The unit should be placed in the coolest area of a room, keeping it away from direct sunlight and other heat sources.
- Let hot foods cool down to room temperature before placing it in the unit.
- Wrap food properly and wipe down drink containers before placing them in the unit.
- Make less trips to the refrigerator by labelling the food.
- The unit should not be aligned with wax paper, paper towel, or aluminum foil because it can interfere with the cooling circulation, making the unit less efficient.

REVERSING THE DOOR SWING

In some applications, you may want the door to open in the opposite direction. To reverse the door swing, follow the instructions below.

Required tools: Flathead screwdriver, Philips screwdriver



1. Place the cooler on its side on a flat, level surface.
2. Remove the cover (part 1) by lifting from the back with a flathead screwdriver. Once the back releases, slide the cover forward to remove. (NOTE: Place a thin towel between the screwdriver and the cooler to avoid scratches.)
3. Remove the upper hinge screws (part 2) using a Philips screwdriver to free the upper hinge (part 5) from the cooler. With the upper hinge removed, slide the door off.
4. Remove the blanking plugs (part 8) from the top and bottom of the door and move them to the other side of the door. You may need to use a flathead screwdriver to remove them.
5. Remove the lower hinge screws (part 6) and both feet (part 7) to free the lower hinge (part 3) from the cooler. Also remove the screw in front of the foot that was not on the side with the hinge.
6. Gently remove the flat cover (part 4) using a flathead screwdriver and mount it to the opposite side of the cooler. Press down to mount.

7. Mount the upper hinge (part 2) in its new location aligning it with the mounting holes. Press the cover (part 1) down over the upper hinge to attach.
8. Align the door on the upper hinge (part 5). Bring the lower hinge (part 3) to the cooler, align it with the door, and fasten it to the cooler using the foot (part 7).
9. Fasten the lower hinge screws (part 6) to the lower hinge to finish mounting the door.
10. Mount the remaining foot (part 7) and screw on the opposite side of the hinge.

DE-ICING THE COOLER

When ice accumulates in the unit, you can de-ice the product manually by using the following steps:

1. Unplug the beverage cooler.
2. Wait for all the ice to melt.
3. Remove water in the unit once the ice has melted.
4. Plug in and restart the unit.

CLEANING THE EXTERIOR:

- Unplug the unit before cleaning.
- Do not use abrasive cleaning products.
- Wash the exterior of the cooler with soap and water only. Then, rinse off the exterior thoroughly.
- Clean the glass door with glass cleaner, or use soap and water with a soft cloth.
- Wipe the temperature control with a damp cloth. Then, dry thoroughly.

CLEANING THE INTERIOR:

- Unplug the unit before cleaning.
 - Do not use abrasive cleaning products.
 - Use soap or a baking soda solution to clean the door gasket. Then, rinse off the product.
 - Apply a thin layer of petroleum jelly to the door gasket to prevent sticking.
 - Use a warm water/baking soda solution inside the unit to clean it.
-

TECHNICAL SPECIFICATIONS

IVABC620SS:

Rated voltage: 115 V 60 Hz

Rated power: 95 W

Dimensions: 16.9" x 17.7" x 22"
(430 x 450 x 560 mm)

Net weight: 37.5 lbs. (17 kg)

Storage capacity: 1.7 cu. ft.

IVABC1010SS:

Rated voltage: 115 V 60 Hz

Rated power: 95 W

Dimensions: 16.9" x 17.7" x 29.1"
(430 x 450 x 740 mm)

Net weight: 47 lbs. (21.3 kg)

Storage capacity: 2.5 cu. ft.

IVABC1010B:

Rated voltage: 115 V 60 Hz

Rated power: 95 W

Dimensions: 16.9" x 17.7" x 29.1"
(430 x 450 x 740 mm)

Net weight: 47 lbs. (21.3 kg)

Storage capacity: 2.5 cu. ft.

IVABC1260B:

Rated voltage: 115 V 60 Hz

Rated power: 90 W

Dimensions: 18.7" x 17.3" x 33.1"
(474 x 440 x 840 mm)

Net weight: 56 lbs. (25.4 kg)

Storage capacity: 3.0 cu. ft.

IVABC1260SS:

Rated voltage: 115 V 60 Hz

Rated power: 90 W

Dimensions: 18.7" x 17.3" x 33.1"
(474 x 440 x 840 mm)

Net weight: 56 lbs. (25.4 kg)

Storage capacity: 3.0 cu. ft.

TROUBLESHOOTING

If the unit doesn't work:

Check to make sure the power supply has the correct voltage. Also check to make sure there isn't a circuit breaker that has been tripped or a fuse that's been blown.

If the unit isn't getting cold enough:

Make sure the temperature settings are adjusted correctly. If so, the room in which the unit is operating might be too hot. Also check whether the glass door has been opened too frequently or has not been completely closed. Check the gasket on the door to make sure it is intact. Make sure the unit has sufficient clearance on all sides.

If the unit vibrates or makes excessive noise:

Make sure the unit has been placed on a level, stable surface. Also check to make sure the fan in the unit is working properly.

If the LED display is not working or shows an error message:

Check to see if the unit is plugged in properly. If so, there may be a problem with the main circuit board that requires professional servicing.

If the buttons don't work:

The temperature control panel may be damaged.

LIMITED WARRANTY TO ORIGINAL CONSUMER

This Ivation® Beverage Refrigerator and Cooler (“Product”), including any accessories included in the original packaging, as supplied and distributed new by an authorized retailer is warranted by C&A Marketing, Inc. (the “Company”) to the original consumer purchaser only, against certain defects in material and workmanship (“Warranty”) as follows:

To receive Warranty service, the original consumer purchaser must contact the Company or its authorized service provider for problem determination and service procedures. Proof of purchase in the form of a bill of sale or receipted invoice, evidencing that the Product is within the applicable Warranty period(s), MUST be presented to the Company or its authorized service provider in order to obtain the requested service.

Service options, parts availability, and response times may vary and may change at any time. In accordance with applicable law, the Company may require that you furnish additional documents and/or comply with registration requirements before receiving warranty service. Please contact our customer service for details on obtaining warranty service:

Email: info@myivation.com

Phone: 866-849-3049

Shipping expenses to the Company’s Return Facility are not covered by this warranty, and must be paid by the consumer. The consumer likewise bears all risk of loss or further damage to the Product until delivery to said facility.

EXCLUSIONS AND LIMITATIONS The Company warrants the Product against defects in materials and workmanship under normal use for a period of ONE (1) YEAR from the date of retail purchase by the original end-user purchaser (“Warranty Period”). If a hardware defect arises and a valid claim is received within the Warranty Period, the Company, at its sole option and to the extent permitted by law, will either (1) repair the Product defect at no charge, using new or refurbished replacement parts, (2) exchange the Product with a Product that is new or which has been manufactured from new or serviceable used parts and is at least functionally equivalent to the original device, or (3) refund the purchase price of the Product.

A replacement Product or part thereof shall enjoy the warranty of the original Product for the remainder of the Warranty Period, or ninety (90) days from the date of replacement or repair, whichever provides you longer protection. When a Product or part is exchanged, any replacement item becomes your property, while the replaced item becomes the Company’s property. Refunds can only be given if the original Product is returned.

This Warranty does not apply to:

- (a) Any non-Ivation® Beverage Refrigerator and Cooler product, hardware or software, even if packaged or sold with the Product;
- (b) Damage caused by use with non-Ivation® Beverage Refrigerator and Cooler products;
- (c) Damage caused by accident, abuse, misuse, flood, fire, earthquake, or other external causes;
- (d) Damage caused by operating the Product outside the permitted or intended uses described by the Company;
- (e) Damage caused by third party services;
- (f) A Product or part that has been modified to alter functionality or capability without the written permission of the Company;
- (g) Consumable parts, such as batteries, fuses, and bulbs;
- (h) Cosmetic damage; or
- (i) If any Ivation® Beverage Refrigerator and Cooler serial number has been removed or defaced.

This Warranty is valid only in the country where the consumer purchased the Product, and only applies to Products purchased and serviced in that country.

The Company does not warrant that the operation of the Product will be uninterrupted or error-free. The Company is not responsible for damage arising from your failure to follow instructions relating to its use.

NOTWITHSTANDING ANYTHING TO THE CONTRARY AND TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, THE COMPANY PROVIDES THE PRODUCT “AS-IS” AND “AS-AVAILABLE” FOR YOUR CONVENIENCE AND THE COMPANY AND ITS LICENSORS AND SUPPLIERS EXPRESSLY DISCLAIM ALL WARRANTIES AND CONDITIONS, WHETHER EXPRESSED, IMPLIED, OR STATUTORY, INCLUDING THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, TITLE, QUIET ENJOYMENT, ACCURACY, AND NON-

INFRINGEMENT OF THIRD-PARTY RIGHTS. THE COMPANY DOES NOT GUARANTEE ANY SPECIFIC RESULTS FROM THE USE OF THE PRODUCT, OR THAT THE COMPANY WILL CONTINUE TO OFFER OR MAKE AVAILABLE THE PRODUCT FOR ANY PARTICULAR LENGTH OF TIME. THE COMPANY FURTHER DISCLAIMS ALL WARRANTIES AFTER THE EXPRESS WARRANTY PERIOD STATED ABOVE.

YOU USE THE PRODUCT AT YOUR OWN DISCRETION AND RISK. YOU WILL BE SOLELY RESPONSIBLE FOR (AND THE COMPANY DISCLAIMS) ANY AND ALL LOSS, LIABILITY, OR DAMAGES RESULTING FROM YOUR USE OF THE PRODUCT.

NO ADVICE OR INFORMATION, WHETHER ORAL OR WRITTEN, OBTAINED BY YOU FROM THE COMPANY OR THROUGH ITS AUTHORIZED SERVICE PROVIDERS SHALL CREATE ANY WARRANTY.

IN NO EVENT WILL THE COMPANY'S TOTAL CUMULATIVE LIABILITY ARISING FROM OR RELATED TO THE PRODUCT, WHETHER IN CONTRACT OR TORT OR OTHERWISE EXCEED THE FEES ACTUALLY PAID BY YOU TO THE COMPANY OR ANY OF ITS AUTHORIZED RESELLERS FOR THE PRODUCT AT ISSUE IN THE LAST YEAR FROM YOUR PURCHASE. THIS LIMITATION IS CUMULATIVE AND WILL NOT BE INCREASED BY THE EXISTENCE OF MORE THAN ONE INCIDENT OR CLAIM. THE COMPANY DISCLAIMS ALL LIABILITY OF ANY KIND OF ITS LICENSORS AND SUPPLIERS. IN NO EVENT WILL THE COMPANY OR ITS LICENSORS, MANUFACTURERS AND SUPPLIERS BE LIABLE FOR ANY INCIDENTAL, DIRECT, INDIRECT, SPECIAL, PUNITIVE, OR CONSEQUENTIAL DAMAGES (SUCH AS, BUT NOT LIMITED TO, DAMAGES FOR LOSS OF PROFITS, BUSINESS, SAVINGS, DATA OR RECORDS) CAUSED BY THE USE, MISUSE, OR INABILITY TO USE THE PRODUCT.

Nothing in these terms shall attempt to exclude liability that cannot be excluded under applicable law. Some countries, states, or provinces do not allow the exclusion or limitation of incidental or consequential damages or allow limitations on warranties, so certain limitations or exclusions may not apply to you. This warranty gives you specific legal rights, and you may have other rights that vary from state to state or province to province. Contact your authorized retailer to determine if another warranty applies.

GET IN TOUCH!

✉ info@myivation.com

☎ 1-866-849-3049

IVATION is a trademark of C&A IP Holdings, LLC, in the U.S., Canada, and the E.U.

All other products, brand names, company names, and logos are trademarks of their respective owners, used merely to identify their respective products, and are not meant to connote any sponsorship, endorsement, or approval.

Distributed by C&A Marketing, Inc., 114 Tived Lane East, Edison, NJ 08837.
MADE IN CHINA

© 2020. C&A IP Holdings, LLC. All Rights Reserved.