




## Assembly Instructions



### **TXB48** Yacht Club 48\" Bench

#### ..... **20-Year Warranty** .....

To view our full warranty, please visit  
[trexfurniture.com/warranty](https://trexfurniture.com/warranty)

#### ..... **Share your space** .....

We love to see where our furniture  
ends up — snap a pic and share  
it with us on Facebook!  
[facebook.com/trexfurniture](https://facebook.com/trexfurniture)

#### ..... **Having Trouble?** .....

If you have questions or concerns regarding  
assembly instructions or missing parts,  
please contact us at **(877) 907-TREX** (8739)  
or email [support@trexfurniture.com](mailto:support@trexfurniture.com)

#### ..... **Cleaning Tips** .....

Keep your Trex Outdoor Furniture™  
looking brand new:

##### **For a quick clean:**

Simply wipe down with soap and water.


##### **For a deeper clean:**

You'll need:

- » 1/3 bleach and 2/3 water solution
- » clean cloth
- » soft bristle brush


Wipe on solution with your cloth  
and let it sit on the lumber for a few  
minutes (this will not affect the color).  
Then, loosen any dirt and debris that  
may catch in surface grooves with a  
soft bristle brush; hose down to rinse.

TOOLS



4mm T-handle  
hex key (included)

PARTS




**A** x 2




1.875" Fine Thread Bolt  
H.25-20X1.875

**B** x 4



1.75" Screw — H.27X1.75


**C** x 5




2.5" Screw — H.27X2.5

1

Do not tighten bolts



2




3


Ensure Fine Thread Bolts are used



1.875" Fine Thread Bolt  
H.25-20X1.875



4



Tighten bolts

