

Owner's Manual

Please review the following instructions and make yourself familiar with the parts and function of your Shade Tech® canopy.

Parts included:

[1] assembled canopy frame


[1] fabric canopy top

[1] storage bag

Set-Up --Step 1: Place the canopy frame only in the center of the setup area. With a partner on the opposite side of the frame, hold the two outer legs and lift slightly for ground clearance. Take a few steps back and extend the frame to full arm's length, approximately four feet (Fig. A).



Step 2: With a partner hold the top and bottom of the eave where it forms a "V" (Fig. B). Lift slightly and slowly walk backward until the frame is fully extended (Fig. C). Take care to avoid pinching your hands or fingers.



Step 3: At each corner, hold the leg of the frame with one hand and lift the slider with the other hand until it clicks past the spring pin (Fig. D).




Step 4: Place the canopy over the top of the frame. Use the hook and loop straps to secure each corner of the cover to the upper portion of each leg (Fig. E).

Step 5: The adjustable legs offer multiple height positions. Tilt one side of the canopy upward and extend a lower leg section until it clicks into place (Fig. F). Repeat on the adjacent leg until all legs are extended. When extending the legs, have a partner hold the frame stable and avoid having only two diagonal legs extended.



Step 6: Fill out included product information card with a stapled copy of your receipt and store in a safe place. Product information can be found on the sticker located on the eave of the frame (Fig. G).

Example



Go to BravoSportsCorp.com/ServiceProductRegistration.aspx and register your new canopy. If you have any issues setting up your canopy, have questions, need parts or accessories call our toll free service line (800) 248-5327.

Take Down --Step 1: Press the leg pin in and lower each leg completely (Fig. H).



Step 2: At each corner, push in the locking button and pull the slider down slowly until the button pops out above the slider (Fig. I). Be careful to not pinch your fingers. Please make sure that all sliders are in an unlocked position below the button prior to attempting to collapse the frame. Closing the frame with any sliders in a locked position will cause damage and/or breakage.



Step 3: Hold the top of the center frame section and lift slightly and slowly, walk toward your partner as the frame folds in (Fig. J). Keep walking until the frame is about half-way closed. Be sure to avoid pinching your hands or fingers. Hold outside legs and continue closing canopy as you walk towards your partner. The completely folded canopy should stand up on it's own (Fig. K).



Step 4: With the canopy standing, slide the bag down slowly until entire canopy is in. Turn the canopy over gently and zipper shut.

Note: The canopy top may remain in place for easier subsequent set-up. However, to prolong the life of the fabric, we recommend that you remove the top when storing your canopy.