




Equipment Sizing Guide



Use the map above to determine your region and compare to the chart below to find your application size.

13 SEER Residential Heat Pump System Sizing for JT4BD Series

Square Footage	Region 1	Region 2	Region 3	Region 4	Region 5	System Size
	940-1300	880-1235	835-1165	680-955	680-955	1.5 TON
	1300-1680	1235-1580	1165-1500	955-1225	955-1225	2.0 TON
	1680-2060	1580-1940	1500-1830	1225-1500	1225-1500	2.5 TON
	2060-2435	1940-2290	1830-2165	1500-1770	1500-1770	3.0 TON
	2435-2810	2290-2645	2165-2500	1770-2045	1770-2045	3.5 TON
	2810-3375	2645-3175	2500-3000	2045-2455	2045-2455	4.0 TON

Residential Sizing: The table and charts are intended to be used as a guideline for Residential applications only. The information is based on conventional window space (<15%), insulation and building construction (8 ft. ceiling height). When including a finished basement, use 1/2 of the finished basement square footage with the rest of the area being calculated.

Mobile/Manufactured Home Sizing: Refer to the Date Plate located in the electrical box or kitchen cabinets. For further assistance, call Hamilton's customer service department (800) 879-0123.