

INSTRUCTIONS

Please read instructions carefully and keep for future reference.

OPERATION

- 1. Install Batteries (Not included).** Battery compartment is located on bottom of statue (Fig. 1). Open the Battery compartment by removing the screws (Fig.2). Install 2 AA 1.5V batteries (FIG.2), match polarity with drawing located on battery compartment. Replace battery cover and secure with screws.
- 2. Activate the Timed Light:** The light operates for 5 hours. Choose the 5 hour span you would like the light to operate. Turn unit over, locate the ON/OFF button. (FIG.1) set to the ON position at the selected time. The light stays on for 5 hours. It is recommended to turn on your light at 7pm, simply press the ON/OFF button to activate, light will light for 5 hours until 12pm and then automatically turn off.
- 3. Reset the timer:** Locate the on/off button on bottom of statuary. Turn unit OFF. Turn unit back ON at the new time you want, the light will come on.

BATTERY LIFE

While the switch is in the ON position, the unit will light up for 5 hours everyday, anywhere, no matter the weather. With everyday use, the battery will last approx. 350 hours or 70 days. When the unit no longer lights properly, replace the batteries. (See install batteries). After replacing the batteries you must reset the timer.

HOW TIMED LIGHTS WORK

This unit is equipped with an automatic timed LED light. When you press the ON/OFF button you activate the timed light, the light will turn on every night at the that time for approx. 350 hours. This will work indoors or outdoors in every kind of weather, rain or shine.

FIG. 1 ON/OFF SWITCH LOCATED ON BOTTOM OF STATUE





FIG. 2 BATTERY COMPARTMENT LOCATED ON BOTTOM OF STATUE



BATTERY INSTALLATION AND REPLACEMENT

Step 1: Battery compartment is located on bottom of statue. Turn unit over to locate the battery compartment (FIG.1). Remove the screws to open the battery compartment (FIG.2)
Step 2: Replace (or install) 2 AA 1.5V alkaline battery (FIG.2). Do Not Mix Old and New Batteries. Do Not Mix Alkaline, Standard (Carbon - Zinc), or Rechargeable (Nickel - Cadmium) Batteries” or equivalent.
Step 3: Replace battery cover and secure with screws. After replacing or installing batteries you must set the timer, see OPERATIONS, step. 2.

MAINTENANCE

After 350 hours or when the unit does not properly light you will need to replace the batteries, see battery replacement section.

TROUBLESHOOTING

If your timed LED light does not work properly, please try the following:

1. Locate the ON/OFF switch, press to the ON position to light the LED light. (FIG.1)
2. Reset your timed lighting, by turning off and turning on at desired time.
3. After replacing or installing batteries you must set the timer, see OPERATIONS, step. 2.
4. Batteries may be weak or worn out. Replace with new AA 1.5V batteries.

IMPORTANT:

1. Use only 1.5V AA alkaline batteries available at local retailers.
2. Check and make sure you have turned on the unit, setting the automatic timer at the selected time.
3. Batteries must be recycled or disposed of properly.

SPECIFICATIONS

1. Battery: 2 pieces 1.5V AA alkaline battery (not included). Battery will need to be replaced approximately after 350 hours of use.
2. LED (Light Emitting Diode) light technology. The product includes: 2 pieces ultra bright LED lights. LED's are highly efficient source of light compared to other types of bulbs and they do not need to be replaced. On average, LED's will last for approximately 25,000 hours or more.
3. Operating time: 5 hours automatic lighting.

WOODS INTERNATIONAL, INC®