

Three Year Limited Warranty

DEWALT will repair, without charge, any defects due to faulty materials or workmanship for three years from the date of purchase. This warranty does not cover part failure due to normal wear or tool abuse. For further detail of warranty coverage and warranty repair information, visit www.dewalt.com or call 1-800-4-DEWALT (1-800-433-9258). This warranty does not apply to accessories or damage caused where repairs have been made or attempted by others. This warranty gives you specific legal rights and you may have other rights which vary in certain states or provinces.

In addition to the warranty, DEWALT tools are covered by our:

1 YEAR FREE SERVICE

DEWALT will maintain the tool and replace worn parts caused by normal use, for free, any time during the first year after purchase.

2 YEARS FREE SERVICE ON XRTM BATTERY PACKS

DC9096, DC9091 and DC9071

90 DAY MONEY BACK GUARANTEE

If you are not completely satisfied with the performance of your DEWALT Power Tool, Laser, or Nailer for any reason, you can return it within 90 days from the date of purchase with a receipt for a full refund – no questions asked.

LATIN AMERICA: This warranty does not apply to products sold in Latin America. For products sold in Latin America, see country specific warranty information contained either in the packaging, call the local company or see website for warranty information.

FREE WARNING LABEL REPLACEMENT: If your warning labels become illegible or are missing, call 1-800-4-DEWALT for a free replacement.



English

Troubleshooting Guide

This guide is intended to assist you in determining why the laser is not operating to your expectations. These are some of the most commonly asked questions or observances. If you still have questions or problems with your DEWALT laser after completely reading through this Troubleshooting Guide and instruction manual, call our toll free Hot Line at 1-800-4-DEWALT or visit one of our service centers.

THE BATTERY WILL NOT LOCK IN PLACE
See "Installing the Battery Pack"

THE LASER WILL NOT TURN ON

Ensure that a fully charged battery is properly inserted into the tool. **TIP:** See "Installing the Battery Pack" section. Rotate the ON/OFF VARIABLE SPEED Knob clockwise to turn the power on. **TIP:** See "Control Panel" section. If the laser still doesn't turn on, take the tool to a DEWALT service center.