Finishes
CP Chrome
PB Polished Brass
BN Brushed Nickel
ORB Oil Rubbed Bronze

BERLIN ACCESSORIES

L:	6 7/8”
W:	2 5/8”
H:	5”

ITPH2110
Berlin Toilet Paper Holder

L:	4 3/4”
W:	4 3/4”
H:	15”

ITBH2110
Berlin Toilet Brush Holder

L:	1 3/4”
W:	3 1/4”
H:	2 3/4”

IRH2110
Berlin Robe Hook



L:	24 1/8”
W:	8 7/8”
H:	6 1/4”

ITRK2110
Berlin Towel Rack

L:	7”
W:	2 1/2”
H:	1 3/4”

ITR2110
Berlin Towel Ring



L:	5”
W:	5 1/8”
H:	1 3/4”

ISD2110
Berlin Soap Dish

Cleaning and Care Instructions:

We recommend you wipe your accessories dry after every use. This will prevent accumulation of mineral deposits left when water evaporates. Use a soft cloth for wiping all surfaces. Avoid harsh and abrasive cleaners on all surfaces. Use only a soft, damp cloth with mild liquid soap to clean the finished surfaces of all accessories, including coated polished brass, gold, brushed nickel, etc.

Finishes
CP Chrome
PB Polished Brass
BN Brushed Nickel
ORB Oil Rubbed Bronze

BERLIN ACCESSORIES

L: 17”
W: 5 1/8”
H: 15 1/8”

IDGS2110
Berlin Double Glass Shelf

L: 24”
W: 5 1/2”
H: 1 3/4”

IGS2110
Berlin Glass Shelf

L: 25 1/4”
W: 3”
H: 1 3/4”

ITB2110-24
Berlin, 24”, Towel Bar

Cleaning and Care Instructions:

We recommend you wipe your accessories dry after every use. This will prevent accumulation of mineral deposits left when water evaporates. Use a soft cloth for wiping all surfaces. Avoid harsh and abrasive cleaners on all surfaces. Use only a soft, damp cloth with mild liquid soap to clean the finished surfaces of all accessories, including coated polished brass, gold, brushed nickel, etc.

L: 29 1/4”
W: 3”
H: 1 3/4”

ITB2110-28
Berlin, 28”, Towel Bar

L: 25 1/4”
W: 5 1/4”
H: 1 3/4”

IDTB2110-24
Berlin, 24”, Double Towel Bar

L: 29 1/4”
W: 5 1/4”
H: 1 3/4”

IDTB2110-28
Berlin, 28”, Double Towel Bar