LT513200TX

Tieman Floor Lamp

Assembly Instructions

Southern ENTERPRISES

For assistance with assembly contact:

Southern Enterprises Inc.
Customer Service 1-800-633-5096
service@seidal.com
www.seidal.com

LT513200TX—Tieman Floor Lamp

Parts List

Please review all parts and hardware before disposing of any packaging. Call Customer Service if missing hardware. Using a screw that is too long will cause damage. Before beginning assembly, separate each type of screw. Carefully study the diagrams below. You may receive extra hardware with your unit.

Mounting Instructions:

1. Attach Post B to lamp base A.
2. Attach lamp body D to Post B.
3. Attach finial C to lamp body D.
4. Attach post H to lamp body D.
5. Mount glass shade E and secure with finial F.
6. Screw the bulb G to the socket.



A. Quantity of 1  Lamp Base	B. Quantity of 2 Post
C. Quantity of 1  Finial	D. Quantity of 1  Lamp Body
E. Quantity of 1 Glass Shade	F. Quantity of 1  Retaining Ring
G. Quantity of 1 Bulb	H. Quantity of 1 Post