Multifunctional storage

Assembly Instructions

X4

X4

Components ▶

|		
	·······	①X1
	·······	②X1
	·······	③X1
	·······	④X1
	·······	⑤X1
	·······	⑥X1
	·······	⑦X1
	·······	⑧X1
	·······	⑨X8
	·······	⑩ X8
	·······	⑪X8
	·······	⑫X8
	·······	⑬X4
	·······	⑭X4
	·······	⑮X8
	·······	⑯X2
	·······	⑰X1
	·······	⑱X1
	·······	⑲X1
	·······	⑳X1
	·······	㉑X1

Screws & Tools ▶

Ⓐ		X68+1
Ⓑ	Ø15 x 9mm	X68+1
Ⓒ	Ø8 x 30mm	X26+1
Ⓓ	Ø6 x 30mm	X16+1
Ⓔ	Ø3.5 x 35mm	X43+2
Ⓕ	Ø3.5 x 12m	X64+2
Ⓖ	Ø3.5 x 12m	X32+1
Ⓗ	300MM	X8sets
Ⓘ		X1sets
Ⓙ		X16
Ⓚ		X2
Ⓛ	M4X8mm	X16
Ⓜ	M6	X1
Ⓝ	M6X30mm	X1

Check all the components & screws before assembly.
Do not install in case part is missing,contact us to get.
Send email with your question to support@idealhouse.vip
We will resend within 24 hours

# How to use the cam lock system

1.Screw cam bolt into panel

2.Push cam into panel - arrow feature on cam top points to panel edge

3.Aligu cam bolt(s) with cam(s) and insert all the way into cross-bored hole(s)

3.Rotate cam(s) clockwise 190°-230° to lock panels together

5.Panels should be tight against each other and connection should be rigid

**Insert the wood dowel 〔C〕at least half way by tapping lightly with a rubber mallet ,IF NECESSARY.**

- Unit must be placed on a level surface or leveled with included hardware (when applicable).
- Do not sit or stand on or allow children to climb,sit or stand on the assembled product.
- For safety reasons,it is imperative that this unit be mounted to the wall.
- Do not use without installing the tip restraint.
- Unit can tip over causing severe injury or death.
- Do not exceed the recommended weight limits.
- Evenly distribute the weight on each level and always keep the heavier loads on the bottom.
- Before cutting,drilling or hammering into any wall or floor surface,verify the location of electrical, plumbing and gas lines.Cutting may cause serious injury.

Ready to assemble the dresser

Before installation, observe each structure of the drawer dresser.
The drawer dresser consists of two main parts. You will assemble the
chest first, and then install the five drawers. Finally, look at the finished
look, and contrast list of part, imagine how to install it faster, hope this
will help you.

Power drill

We recommend using a power
drill to assemble。

Step 1

-Attach Ⓐ to ⑱&⑲&⑳&㉑

Tighten Ⓐ clockwise until all of
their threads are engaged.

Ⓐ X12

⑳

⑱

㉑

⑲

Ⓐ 12X

Step 2

- Attach Ⓒ to ③&④
- Attach⑱&⑳to③as below shown
- Attach⑲&㉑to④as below shown
- Screw Ⓑ to lock the③&④as below shown

Ⓑ 🔩 12X

Ⓒ ⬛ Ø8 x 30mm 8X

③

Ⓒ X8

⑱

⑳

Ⓑ X12

④

㉑

⑲

Warm Tips: Make sure the 4 large pre-drilled hole are on the upside ③&④holes should be in the same side.

# Step 3

-Attach Ⓐ to ③ as below shown

-Install the drawer slides Ⓗ on the left right side panel ③. When building it make sure to take note of the drawer slides is the one with a flat end.

Ⓐ ⬤ 4X

Ⓕ 🔩 Ø3.5*12mm 8X

Ⓗ ▬ 300MM CL 4X

Make sure the 4 large pre-drilled hole are on the upside.

Ⓕ should be locked in the Second hole against the pulley.

Ⓕ X8

Ⓐ X4

③

Ⓕ should be screw to the small holes

Ⓕ   Ⓕ

Ⓗ

CL

7

Step 4

-Attach Ⓐto⑤as below shown

-Install the drawer slidesⒽ on the left right side panel⑤. When building it make sure to take note of the drawer slides is the one with a flat end.

Tighten Ⓐ clockwise until all of their threads are engaged.

| Ⓐ | 1X | Ⓕ ∅3.5*12mm 8X | Ⓗ 300MM CL 4X |

Make sure the 4 large pre-drilled hole are on the upside.

Ⓕ should be locked in the Second hole against the pulley.

ⒻX8

ⒶX1

⑤

Ⓕ should be screw to the small holes

Ⓕ   Ⓕ

Ⓗ

CL

Install first rail on the right side of board ⑤ .

Step 5

-Attach Ⓐ to ⑤ as below shown

-Install the drawer slides Ⓗ on the left right side panel ⑤. When building it make sure to take note of the drawer slides is the one with a flat end.

Ⓐ	Ⓕ	Ⓗ
1X	⌀3.5*12mm 8X	300MM CR 4X

Make sure the 4 large pre-drilled hole are on the upside.

Ⓕ should be locked in the first hole against the pulley.

ⒻX8

ⒶX1

Ⓕ should be screw to the small holes

⑤

Ⓕ   Ⓕ

Ⓗ

CR

Install second rail on the left side of board   .

9

Step 6

-Attach Ⓐ to ④ as below shown

-Install the drawer slides Ⓗ on the left right side panel ④. When building it make sure to take note of the drawer slides is the one with a flat end.

Ⓐ	Ⓕ ∅3.5∗12mm	Ⓗ 300MM CR
4X	6X	3X

Make sure the 4 large pre-drilled hole are on the upside.

Ⓕ should be locked in the second hole against the pulley.

Ⓕ X8

Ⓐ X4

④

Ⓕ should be screw to the small holes

Ⓕ   Ⓕ

Ⓗ

CR

Step 7

-Attach②&⑧&⑥to⑤as below shown

-Stick Ⓔto⑥&⑤,use Ⓘ locked

-Stick Ⓔ to②&⑤,useⓉlocked

-Screw Ⓑ to lock the⑧as below shown

| Ⓑ	Ⓔ ⌀3.5*35mm	Ⓒ ⌀8*30mm
1X	3X	3X

The two boards fit vertically,
place(B) and match their holes
with（A）then tighten（B）clockwise.

steps 1　steps 2　steps 3

Ⓘ

ⒺX3

ⒸX3

ⒷX1

⑥

⑤

⑧

②

Step 8

-Attach ⑦ to ⑤ as below shown

-Screw Ⓑ to lock the ⑦ as below shown

The two boards fit vertically,
place(B) and match their holes
with (A) then tighten (B) clockwise.

steps 1   steps 2   steps 3

Ⓒ X1

Ⓑ X1

Ⓘ

⑤

⑦

12

Step 9

-Attach ③ to②&⑥&⑦as below shown

-Screw Ⓑ to lock the②&⑥&⑦as below shown

steps 1   steps 2   steps 3

The two boards fit vertically,
place(B) and match their holes
with (A) then tighten (B) clockwise.

⑥

③

⑦

②

C X4

Ⓑ X4

Ⅰ

Step 10

-Attach ④ to②&⑥&⑧as below shown

-Screw Ⓑ to lock the②&⑥&⑧as below shown

-Stick Ⓝ to②&⑰,useⓃlocked

Ⓑ 4X

Ⓒ ∅8*30mm 4X

steps 1 steps 2 steps 3

The two boards fit vertically,
place(B) and match their holes
with (A) then tighten (B) clockwise.

ⒸX4 ⒷX4

④

⑥

⑧

②

⑰

⑰ Ⓝ

Ⓜ

Step 11

-attach Ⓐ to ① as below shown

Ⓐ   6X

Tighten Ⓐ clockwise until all of
their threads are engaged.

Step 12

-Attach ① to ③&④&⑤as below shown

-Screw Ⓑ to lock the①as below shown

| B	C
6X	⌀8*30mm 6X

steps 1   steps 2   steps 3

The two boards fit vertically,
place(B) and match their holes
with (A) then tighten (B) clockwise.

Ⓒ X6

Ⓑ X6

①

③

⑤

④

Step 13

-Screw Ⓖ to Back panel ⑯ as below shown

-Stick Ⓚ to①&⑯,use①locked

Ⓖ 32X

Ⓚ 2X

Ⓚ X2

Ⓖ X32

Ⓘ

①

③

⑯

⑯

Warm Tips: 1:It is recommended to put the product upside down
When installing the back panel.
2:It is recommended to attach the back panel⑩at
the top panel①first

Step 14

-Screw Ⓐ to ⑬/⑭ as below shown

-Attarch ⑨&⑩&⑫ to ⑬/⑭ as below shown

-Screw Ⓑ to lock the ⑨&⑩&⑫ as blow show

| Ⓐ		Ⓑ		Ⓓ	
	40X		40X	φ6*30	16X

Tighten Ⓐ clockwise until all of their threads are engaged.

The two boards fit vertically, place(B) and match their holes with (A) then tighten (B) clockwise.

steps 1 steps 2 steps 3

X8

The long groove on the panel is used to install the bottom plate.Please make sure all grooves of these boards are on the same side.

Ⓑ X5

Ⓓ X2

X8

Step 15

-Attach⑮&⑪to⑨&⑩as below shown

-Screw Ⓔ to attach⑨& ⑩&⑪to⑪& ⑫ as below shown

Ⓔ X5

⑪

⑮

⑨

⑫

⑩

⑬ /⑭

X8

Step 16

-Screw Ⓛ & Ⓙ to ⑬ / ⑭ attach as below shown

Ⓙ 16X

Ⓛ 16X

Ⓙ X2

Ⓛ X2

⑬ / ⑭

⑨

⑮

⑪

⑩

X8

Step 17

-Install the drawer slides Ⓗ on the drawer side
 panels ⑨ & ⑩ as below shown

| J | 🔩 32X | H | ▬ 16X |

-The roller is
 facing backward

X8

-Repeat the previous step to install the remaining drawers

Step 18

cabinetmember

roller

roller

drawerrunner

Step 19

The furniture must permanently be fixed to the wall using the provided anti-tipping device to prevent it from tipping over.

·Mark the drill positions on the wall with a pencil.

·Drill a small hole on the marked positions.

·Insert a wall anchor into the drilled hole.

·Fix the anti-tipping strap to the wall using the provided screws.