USER MANUAL

LP290V3

Compact 300L Grip

2 AA Batteries



FEATURES

- TACKGRIP®
- LPE Optics™
- Pocket Clip

ANSI/PLATO FL1 STANDARD

MODES	LUMENS	RUN TIME	BEAM DISTANCE
High	300 lm	2H 45M	100
Low	100 lm	7H 30M	55
Strobe	300 lm	X	X

OPERATION INSTRUCTIONS

On/Off: Press and release the button on the tail cap to turn the light on and off.

Cycle Modes: Half-press button on tail cap to cycle through modes (High/Low/Strobe).



BATTERY REPLACEMENT

Battery Replacement: The LP290V3 uses 2 AA.
To replace the batteries, turn the tail cap counterclockwise to remove it. Slide out the old batteries and insert new batteries according to the (+/-) symbols. For best results, we recommend using brand new alkaline batteries that are the same voltage and brand. Re-attach the tail cap by pressing down lightly and turning it clockwise until tight.

If you know it will be a while between uses, we suggest removing the batteries from the flashlight and storing it in a dry, protected place.



PRODUCT WARRANTY

The LP290V3 has a Limited Lifetime Warranty Against Manufacturer's Defects from time of purchase.
For warranty claims please contact us by calling 801-553-8886 or sending an email to info@luxpro.com

14725 S Porter Rockwell Blvd Ste C
Bluffdale, UT 84065