Mounting hardware included

1. Mark the desired height and drill a 1/8" hole
2. While holding the pole socket fasten the screw into the wall
3. Repeat the first two steps for the second socket