EASY SET-UP INSTRUCTIONS

Required Tools: Drill, Ladder, Hammer, Pliers, Bolt Cutters (for chain install), Tape Measure, Pencil.

---Turn off the switch and circuit breaker before installing this LED high bay light fixture.
---Drill a pilot hole, then securely install your hook in the ceiling or adequate support. If using a chain, cut to correct size to suspend light
---Screw the provided lifting ring clockwise into the UFO High Bay fixture, then tighten firmly Add and tighten ring screw.
---The UFO LED high-bay lights with a 5ft power cord and work for 110-277V.

---Hang the fixture onto your ceiling hook or chain with the lifting ring.

- Chain and ceiling hook not included.

---Wiring the light as below:

---Turn on circuit breaker and test the light.



Type	UFO LED High Bay Light
Power	100W/150W/200W
Lumen	16500lm/24000lm/32000lm
Power Frequency	50 / 60Hz
Color temperature	5000K
Dimmable	No Dimmable
Voltage	110-277V

We appreciate your purchase! Please read the instruction manual before installation and keep it for future reference.

Warning

- 1. To avoid damage, falling, electric shock or fire, please do not modify the lamp or replace accessories without confirming with the supplier first.
- 2. Please authorize only qualified personnel to install the lamp and ensure they follow the instruction manual. Any improper installation might cause falling, electric shock, fire, or other injury, damage or hazard.
- 3. Please disconnect power before installation or any maintenance of the lamp.
- 4. Please disconnect power if it begins to smoke or emit odors, since fire or electric shock may occur. Ask qualified person to inspect and maintain the lamp.
- 5. Please do not dismantle the lamp without the supplier’s authorization.
- 6. Please do not touch the power supply, when the lamp is operating.
- 7. Terminal block not included. The electrical fitting must be installed by a licensed electrician.
- 8. The light source contained in this lamp shall only be replaced by the manufacturer, service agent, qualified person.