4AA

Batteries Required
(Batteries included for demo purposes only.)

RUDOLPH THE RED-NOSED REINDEER®



5.9V 2A DC Adapter Ready
(Adapter not included, sold separately.)

MISFIT ELEPHANT™

Sound, Motion and Wireless MIT Activated

OPERATING INSTRUCTIONS

1. Insert 4 AA batteries (included) into the battery compartment located on the control box.
2. OR plug a 5.9V 2A DC adapter (not included) into the control box. Fully secure adapter by twisting it tight. Do not overtighten.
3. Move the control switch to the ON position. Make a loud sound (clap), or move in front of the item to activate the jolly sequence!
4. If you purchased all (3) Misfit toys — (8251790) Animated Misfit Doll™, (8251791) Misfit Elephant™ and (8251792) Animated Charlie-in-the-Box™ — you can move the switch to the MIT position to play all (3) items together. Ensure all (3) items are within 15 feet of each other.
5. Turn the switch to the OFF (DEMO) position when not in use.

   NOTE: When the item is in MIT mode, battery consumption will be significantly higher than in standard operation.

OPTIONAL DEMO/FOOTPAD SETUP

FOOTPAD IS NOT INCLUDED. MUST BE PURCHASED SEPARATELY.

1. Insert the cable from the (optional) compatible footpad into the jack labeled DEMO JACK located on the control box.
2. Place the power switch to the OFF (DEMO) position to enable demo/ footpad activation.
3. Step on the (compatible) footpad to activate the jolly sequence!

   * *Compatible footpads are sold separately and can be purchased at **tekkycreations.com.***

ITEM #8251791 / MODEL #96913

INCLUDES:
(1) RUDOLPH THE RED-NOSED REINDEER® MISFIT ELEPHANT™ decoration. Surface washable only.
ALL NEW MATERIALS: plastic.

FCC STATEMENT

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This device must not be co-located or operating in conjunction with any other antenna or transmitter. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC ID: 2AAAI-TEKKY-MIT3

To comply with FCC's RF radiation exposure limits for general population/ uncontrolled exposure, this device must be installed to provide a separation distance of at least 20cm from all persons.

WARNING: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

RUDOLPH THE RED-NOSED REINDEER® Official Licensed Product

Rudolph the Red-Nosed Reindeer
© & ® or TM The Rudolph Co., L.P.
All elements under license to
Character Arts, LLC. All rights reserved.

TEKKY®

TEKKY® and the logo design are trademarks of JCW Investments, Inc., d/b/a Tekky, and used under license.

support@tekkydesign.com