MOEN

Illustrated Parts

Garbage Disposals

MODEL GX100c

■ **Order by Part Number**

Stopper - Polished Stainless
1011

Removable Splash Guard
1016

Sink Flange - Polished Stainless
1017

Mounting Assembly Kit - 1824

Fiber Gasket



Backup Flange

Screws (x3)

Mounting Ring

Snap Ring

Cushion Mount

Lower Mounting Ring

Drain Elbow Kit - 1026

Rubber Gasket

Screws



Drain Elbow

Replacement Power Cord Kit
1024

Other Available Accessories

Air Switch Remote Controller

- Installs into existing sink hole to operate disposer with plunger air switch.
- Perfect application for island countertops or where electrical switch is unavailable.
- No wiring connections or code restrictions.

Air Switch Base Unit	
Air Switch Remote Controller	ARC-4200
Additional Air Switch Button Finish Options:	
Chrome	AS-4201-CH
Satin Nickel	AS-4201-SN
Polished Brass	AS-4201-BR
White	AS-4201-WH
Almond	AS-4201-AL
Biscuit	AS-4201-BIS

Optional:

Dishwasher Connector Kit
1023

Unjamming Wrench
1037



TO ORDER PARTS CALL: 1-800-BUY-MOEN
www.moen.com