Ceiling Light Installation Instruction

Please read the instruction manual carefully before using

Dear Customer,

Thank you for choosing us! To save your time and effort, please try to light up the lamp before installation to ensure the sockets are working correctly. If you have any issue when you receive the lamp, please feel free to contact us .

Thank you for your support!

- Customer Support Team

Specification	
Voltage	110-120V
Bulb Socket	E12
Wattage	Max 40W /Bulb
Bulb Type	Incandescent/LED/Halogen (Not Included)
Certification	Socket is UL Listed
Warranty	2 Years

Package List	
Rattan Cover	1
Pack of Hardware	1
Canopy	1
Round Tube	1
Top Cover	1



Installation Step

1. Fixing the bracket: Attach the metal bracket to your junction box with Phillips head screws. (Anchor screws are only useful for those customers who do not have a junction box).
2. Hard-Wired: Connect the "L" wire to your "live" wire through the orange terminal caps and the "N" wire to your "neutral" wire, the copper wire needs to be wrapped around the green screw.
3. Attach the canopy to the metal bracket with screws.
4. Insert the bulbs into the ceiling light. (Bulbs not included)
5. Rotate the round tube against the hole in the canopy until it is tightened, then twist the silver tooth rod onto the round tube.
6. Align the round tube with the round hole on the cover and fix it with a hexagon nut, and finally twist the top cover and round nut.

Q: The lamp does not work?

If your bulb is working properly, the ceiling light is unresponsive, please pull the copper piece which is located in the bulb sockets. This operation is to ensure that the bulbs make good contact with the copper piece in the bulb sockets.