INSTRUCTION MANUAL FOR TREE FUNCTIONS



Notes :

- The Power On/Off , functions and lighting modes can be controlled with either the remote control or the foot pedal.
- Press function switch (FN) of remote control to select function; Continuous press (FN) to cycle the functions.



Foot Pedal

Function Order on Foot Pedal	Function Description
1	Steady
2	Fade In/Out
3	Twinkling
4	Off

GE is a trademark of General Electric Company
and is under license by Nicolas Holiday Limited

Questions, call customer service toll free at
1-877-398-7337 or visit us on web at
www.geholidaylighting.com

NHL Model No. 24109LO 24129LO
Remote Control: TS-T04AN
Printed in China
FP24

MANUAL DE INSTRUCCIONES DE LAS FUNCIONES DEL ÁRBOL



Notas :

- **Las funciones de encendido/apagado y los modos de iluminación pueden controlarse con el control remoto o con el pedal.**
- **Presione el interruptor de función (FN) del control remoto para seleccionar la función; Presione de forma continua (FN) para alternar entre las funciones.**



Pedido de funciones en el pedal	Descripción de funciones
1	Constante
2	Aparición y desaparición
3	Destellante
4	Apagado

GE es una marca registrada de General Electric Company
y se utiliza con licencia por Nicolas Holiday Limited

Si tiene preguntas, llame al número gratuito del Servicio al Cliente al 1-877-398-7337 o visítenos en el sitio web www.geholidaylighting.com

NHL Model No. 24109LO 24129LO
Control remoto : TS-T04AN
Impreso en China
FP24