
USER MANUAL AND OPERATING INSTRUCTIONS

READ & SAVE THESE INSTRUCTIONS



INDUSTRIAL HEAVY DUTY DRUM FAN

120V / 60Hz, 5.7A

SAFETY INFORMATION

WARNING

1. Read and save these instructions. Do not operate fan unless you have read these instructions.
2. Unplug the fan before moving it or performing maintenance. Do not touch the fan when your hands are wet.
3. Those who are not qualified electricians should not disassemble, repair or rebuild the fan.
4. Unplug the fan when it is not in use.
5. DO NOT unplug the fan by pulling the cable cord. Unplug by holding the plug and pulling.
6. DO NOT use the fan when there is damage to the cable cord or plug. If the supply cord is damaged, it has to be replaced by the manufacturer, its service agent or similarly qualified persons.
7. To Reduce The Risk Of Fire, Electric Shock Or Injury To Persons, Do Not Use Replacement Parts That Have Not Been Recommended By The Manufacturer (e.g. Parts Made At Home Using A 3D Printer).
8. DO NOT use the fan close to fires.
9. DO NOT insert your hand or other objects into the grille or the movable parts.
10. To reduce the risk of fire or electric shock, do not use this fan with any solid-state speed control device.
11. Do Not Use An Extension Cord With This Fan.

CAUTION

1. Unplug the fan from the socket and clean it with a soft cloth.
2. DO NOT immerse the fan.
3. Fit the guard onto fan before starting up the fan.
4. This fan is not intended for use by people (including children) with reduced physical, sensory or mental capabilities or lack of experience and knowledge unless they have been given supervision or instruction concerning use of the fan by a person responsible for their safety. Supervise children to ensure they do not play with the fan.
5. To reduce the risk of electric shock during outdoor use, connect only to an outlet provided with a ground fault circuit interrupting device.


TECHNICAL SPECIFICATIONS

ITEM NO.	MODEL NO.	VOLTE/Hz	CURRENT(A)
C42DF	SFDC-950F	120V/60Hz	5.7A

PACKAGE CONTENTS

⚠ Caution


Please take away all parts from stuffing material inside the box before dispose the package.




Part	Description	Quantity
1	Fan Body	1
2	Wheel Shaft	1
3	Wheel	2
4	Foot Pad	2

ASSEMBLY INSTRUCTION

1. Loosen the screw, flat washer, spring washer and nut from Foot Pad. Save them for next step.




2. Install the Foot Pad with bottom bracket by screw, flat washer, spring washer and nut.




ASSEMBLY INSTRUCTION(CONTINUE)


3. Loosen 6 screws from Wheel Shaft, and save them for next step.



4. Insert the Wheel Shaft through the bracket of fan bottom, and fix it with two screws.




5. Fastening another two screws into Wheel Shaft for position-limit.




ASSEMBLY INSTRUCTION(CONTINUE)

6. Install two Wheels into Wheel Shaft.




7. Fix two Wheels with Wheel Shaft by two screws.



OPERATION INSTURCTION

1. Place the fan on a safe, flat surface where it can not fall or be pulled by the cord.
2. Adjust the desired speed by rotating the switch knob at the control box.




CARE AND MAINTENANCE

Unplug the appliance before cleaning. Don't use any water for cleaning metal surfaces. Slightly moisten a cloth and then wipe off the surfaces of the fan. In order to remove dust from the grill, use a vacuum cleaner or remove the front grill by removing the securing screws on the edge of the grill. After cleaning, remount the grill. After doing this, fasten the screws on the edge of the grill.

1-YEAR LIMITED WARRANTY

The manufacturer warrants this product to be free from manufacturing defects in the material and workmanship under normal use for a period of one year after the date of purchase by the original purchaser.
This warranty does not cover transit damages. This warranty does not apply to damages from accident, misuse, alteration of any kind to the fan or where the connected voltage is more than above the nameplate voltage. This warranty does not apply to the finish on any portion of the product. Servicing performed by unauthorized persons shall render the warranty invalid. The warranty is not responsible for damages of any kind, including accident and consequential damages. Some states do not allow the exclusion or limitation of the incidental or consequential damages, so the above exclusion or limitation may not apply to you. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

REPLACEMENT PARTS LIST



PART	DESCRIPTION	PART #
1	Blade	C42DF-1
2	Wheel	C42DF-2