
SKERI



USER MANUAL

Electric bicycle

Please note before use

1.Before the first time of driving, please read this user manual carefully about the cautions and safety specification. Or you can ask a director (coach) of driving experience for instruction.

2.The first charging shall be of 6-8 hrs. When the indicator of charger turns fromred to green, it means the battery is in full charged.

3.When all preparation works are done, in order to ensure safety and prevent from injury, please wear the safety helmet and protective gear.

Maintenance

1.If there are stains on the surface of the electric bicycle, wipe it with a soft cloth dipped in a small amount of water. If there are stubborn stains, use a toothbrush dipped in a small amount of toothpaste to scrub repeatedly, and then wipe it with a soft cloth dipped in water.

2.Do not use alcohol, kerosene, or other corrosive volatile solvent cleaning, otherwise it will damage the appearance and internal structure of the product.

3.Prohibit the use of pressure water gun spray rinse, and ensure that the bicycle is closed when cleaning, charging port rubber cap tightly, otherwise it may lead to serious consequences.

4.If you do not use the electric bicycle for a long time, please place the electric bicycle indoors in a dry and cool place, and try to avoid outdoor exposure to the sun. Otherwise, the appearance and tires of the electric bicycle will accelerate aging, and the life of the battery pack will be significantly reduced.

5.Do not use battery packs that are not original. Otherwise, risks may arise.

6.Do not open or Pierce the shell of the bicycle. Avoid direct contact of metal objects with the battery contact points, to avoid battery damage or casualties.

7.When disposing of the battery string, follow the local laws and regulations. Do not dispose of the battery string at will and protect the natural environment.

8.If not used for a long time, please charge the battery pack for 3 hours every 3 months.

Read all precautions and instructions in this manual before using this equipment

Assembly Caution ---------- 3

Part List ---------- 4

Part List ---------- 5

Front Wheel Installation ---------- 6

Front Fender And Headlight Installation ---------- 7

Pedal Installation ---------- 8

Handlebar Installation ---------- 9

Rear Shock Absorber Installation ---------- 10

Kickstand Installation ---------- 11

Battery Installation ---------- 12

Part Name ---------- 13

Function Introduction ---------- 14

After-Sale Information ---------- 15-16

ASSEMBLY CAUTION

Please carefully read the following information before installation

Assembling requires at least two people
Do not tighten all screws before assembly is complete
Ensure that all accessories are complete. If not, please contact us via email



If you are missing any parts, or otherwise
have any warranty issues, please contact us first.

Shortcut: A Lot of People Doing That Way

To enhance your installation process for both speed and convenience, consider removing all accessories from the box, carefully opening the packaging, and arranging everything neatly on the floor. This preparation can streamline your setup experience.

WARNING



Choking hazard. Small parts-Please exercise caution if smallchildren or pets are present.












Sharp objects may be involved. Use precaution and protection.








Heavy object. Use lifting aids and proper lifting techniques when moving

Part List

A1 .Front Fender 1PC	A2 .Front Wheel 1PC	A3 .Battery 1PC
		
A4 .Headlight 1PC	A5 .Nylon cable tie 3PC	A6 .Pedal Left 1PC
		
A7 .Pedal Right 1PC	A8 .Charger 1PC	A9 .Phone holder 1PC
		

Part List

A10 .Frame assembly 1PC	A11 .Inflator 1PC	A12 .Key（Pay attention to save）1PC
		
A13 .Tools	A14 .Lock 1PC	A15 .Quick-Release Lever 1PC
		

Front Wheel Installation

1) Insert the front wheel in between the front fork on the bike. Be sure the fork is resting on the outside of the axle.

2) Align the disk between the brake caliper as shown in Figure 2.


3) Insert the skewer into the wheel axle as seen shown. Keep the anti-rotation piece,springs,cam follower, and lever on the LEFT side, nearest the disk brake. Keep the adjustment nut ,anti-rotation piece and springs on the RIGHT side. (See Figure 2)

4) Fix the anti-rotation piece hook into the hole on the fork; Screw the skewer into the end nut until almost tight.

5) Lift the lever up until parallel with the front fork. You should feel the axle tighten into the front forks. Your front wheel is now installed.


Figure 1

Bike Front




Align the anti-rotation piece with the corresponding position on the front fork.

Figure 2



Front Fender And Headlight Installation




Fender Assembly

1) Take out the screws and washers fixed on the fork fender mounting holes both in right and left side and fix the fender stay with those screws and washes. Adjust the fender paralleled with the front wheel and then tighten the screws.

2) Put the lifting lug of the fender behind fork gantry installing hole. Link and secure these two pieces with the fixing screw and washer.

Head Light Assembly


Move the headlight bracket straight forwarder. Take out the screws both on the left and right side. Fix the screws onto the I and K hole on the bracket with headlight. Secure tightly the H and J screws on the left and right side of bracket.



Pedal Installation

Warning: Face front, distinguish left and right;
1.The left pedal must be installed on the left crank, and the right pedal on the right crank."
2.Pedal need to be tightened with (15mm) wrench (be sure to tighten to avoid loose pedal);

Front



Rear

Handlebar Installation

1)Remove 4 No. 2 screws from the corresponding positions on the diagram.


2)First, make sure the front wheel and the front fork are pointing straight forward. Then, adjust the component that fixes the handlebar to point straight forward. First tighten screw 3, then tighten screw 4.


3)Place the handlebar in the middle of stem being careful with the wires.

4)Adjust the angle of the handlebars to suit your riding posture.Lock all the No. 2 screws as shown in the diagram.


5)Check whether all headset screws are tight.

6)Adjust the display screen to the appropriate angle and tighten all the No. 1 screws.







Rear Shock Absorber Installation




Align the screw A with the frame position and shock absorber hole position a shown in the diagram and tighten it, then align the screw B with the frame position and shock absorter hole position b shown in the diagram and
tighten it.



Completion status



Kickstand Installation



Tips:
Once open the carton, take out the bike and place it on a soft and clean area. Assemble the stand on the frame rear fork by driving two screws into the frame.


Battery Installation


1.Insert the battery pack into the oblique rear as shown in the picture. After hearing the click sound, the battery is installed in place; Rotate the key clockwise 180 ° to lock the battery.


2. Insert the key into the lock hole, turn to the unlocking position, rotate counterclockwise 180° to unlock the battery. and exert upward force on the Angle (in the opposite direction to the installation of the battery) to remove the battery

3.Please keep the key safe.

A key is required to remove the battery










180°clockwise to lock
180° counterclockwise to unlock


Part Name


charging port
Battery Lock
Headlight
Seat
Rear shock absorber
Fork
Motor
Disc Brake
Disc Brake
Crank Set
Pedal
Chain
Kickstand
Freewheel
Rear Dereilleurl


Brake Lever
Brake Lever
Light Button
The turn signal button
Speaker button
Swich set
Display
Shifter
Throttle


Function Introduction





1. Long press the "⏻" key to start up, 20 minutes without operation automatically shut down;
2. Long press the "-" key to enter boost mode and release to stop;
3. Short press the "+" or "-" keys to switch the gear, there are 5 gears in total, the default gear is 0 when the machine is turned on, and the gear has no memory;
4. After turning on, press the "M" key briefly to switch the numerical display mode .

FORMAT OF AFTER-SALE EMAIL



Welcome to send us some pictures to describe your problem, which will help us better and faster understand your current situation, and thus provide you with the best solution.

The machine you ordered has been carefully inspected and is fully guaranteed to be in perfect working order. This lifetime warranty covers missing parts, damaged parts, package lost, all manufacturing and mechanical defects, excluding malfunctions or deterioration resulting from accidents or negligence. with this card, you are entitled to obtain service at any platform, such as Amazon, Walmart, and our own website.

Please provide your Platform and Order Number to us in the email subject.

NEED HELP?
CONTACT US FIRST.

skeri-service@outlook.com