EDGESTAR®

Document Type: Dimensional Drawing
Model: KC7000BL
Version: 2.0 12102019

Exterior Dimensions



Front View



Side View



Top View

EdgeStar, 8606 Wall St, Suite 1600, Austin, TX 78754
www.edgestar.com • contact@edgestar.com

**Warranty service should be performed by an authorized service representative only.*

EDGESTAR®

Document Type: Dimensional Drawing
Model: KC7000BL
Version: 2.0 12102019

Exterior Dimensions with Tower



Front View



Side View



Top View

*Tower dimensions are approximate and may vary depending on your customized setup. In order for your unit to cool and operate correctly, the tower must be installed per the instructions in the user's manual. It is highly recommended that you have the unit onsite before making any modifications to countertops or cabinetry in order to accommodate the tower. Improper installation may void the warranty. EdgeStar and its affiliate companies are not responsible for damage incurred through the installation process.

EdgeStar, 8606 Wall St, Suite 1600, Austin, TX 78754
www.edgestar.com • contact@edgestar.com

**Warranty service should be performed by an authorized service representative only.*

EDGESTAR®

Document Type: Dimensional Drawing
Model: KC7000BL
Version: 2.0 12102019

Interior Dimensions



Front View



Side View



Top View

EdgeStar, 8606 Wall St, Suite 1600, Austin, TX 78754
www.edgestar.com • contact@edgestar.com

**Warranty service should be performed by an authorized service representative only.*

EDGESTAR®

Document Type: Dimensional Drawing
Model: KC7000BL
Version: 2.0 12102019

Door Swing



EdgeStar, 8606 Wall St, Suite 1600, Austin, TX 78754
www.edgestar.com • contact@edgestar.com

**Warranty service should be performed by an authorized service representative only.*