PRODUCT INSTRUCTIONS

Thank you for choosing our products.



(Please read carefully before installation)

TABLE OF CONTENTS

1. SAFETY INFORMATION
2. PRE-INSTALLATION ADVICE
3. ACCESSORIES LIST
4. INSTALLATIONSSCHRITTE
5. INSTALLATION STEPS
6. FERNBEDIENUNG BENUTZUNG
7. IMPORTANT:PAIRING BETWEEN REMOTE AND RECEIVER
8. COMMON TROUBLESHOOTING

SAFETY INFORMATION

WARNING

To avoid fire, shock and serious personal injury, please read the follwing instructions caref ully.Important Safety Instructions.

- Before installing the fan, disconnect the power by removing fuses or turning off circuit breakers.
- Make sure the installation site you choose allows a minimum of 7.5 fet from the blades to the floor and at least 30 inches from the tip of the blades to any obstruction.
-The outlet box andits support must be able to support the moving weight of the fan (at least 45kgs.). Do not use a plastic outlet box.
- Attach the mounting bracket by using the hardware supplied with the ceiling outlet box.
- After installing the fan, make sure all the colections are secured. This will prevent the fan from falling.
- Do not insert anythinginto the fan blades while the fanis operating.
- Turn the fan off and wait for it to stop before reversing fan direction.
- To reduce risk of electrical shock and personal injury, do not install the fan on a sloped ceiling.
- To reduce the risk of electrical shock and personal injury, do not use this fan with any solid-state.
- To reduce risk of personal injury, use only the two steel screws and lock washers provided with the fan for mounting the outle box.

Risk Of Electric Shock

- Before you start installing this ceiling fan, disconnect the power supply by turning off the circuit breaker. (see the picture at the next page.)
- All electrical connections must be in accordance with local and National Electric Code (N.E.C.) standards and ANSI/ NFPA 70.
- Consult a qualified electrician if you are unfamiliar with proper electrical wiring connections.
- Do not alter, re-locate or remove wiring when nothing goes wrong with the product.
- Double-check all connections and screws to be sure they are tight and correct.
- Verify whether the supply voltage is correct by comparing it with the product information.

Risk Of Injury

- Keep all the parts of this product away from children. The package contains many small or heavy parts that may bring the risk of choke or injury.
- Make sure to install all parts firmly enough in case they fall while running. Carefully check all screws, bolts, and washers on the fan assembly to ensure they are secured.
- Wear safety gloves and safety glasses always when instaling or removing the light or the fan, or performing maintenance.
- Some parts of the components are sharp and may hurt your hands, please make sure you are wearing safety gloves when touching and installing the components.
- Wear rubber-soled shoes and work on a sturdy ladder.

Maintenance And Cleaning

- Periodically cleaning your celing fan is the only required maintenance. Use a soft brush or lint free cloth to avoid scratching the paint. Please turn off the electricity power before you clean your fan.
- Do not use water when cleaning your ceiing fan. It could damage the motor or the blades or even evoke an electrical shock.
- The motor has permanently lubricated ball bearing.
- No need to oil.

MAKE SURE THE POWER IS OFF IN THE ELECTRICAL PANEL BOX BEFORE YOU DO ANY CLEANING OR REPAIRS

PRE-INSTALLATION ADVICE

WARNING

To avoid serious injury or death, turn off the power at the circuit breaker before installing the fan.



OFF

INSTALLATION DISTANCE REFERENCE



TOOLS NEEDED



Phillps Screwdriver |



Wire Stripper |



Step Ladder |



Safety Gloves

ACCESSORIES LIST







Receiver&Remote

If any parts are missing or broken, please contact us.

Installationsschritte



1



OFF

2



3



4



5



6



7



8



ON



Effect picture after installation

This is the central point of the lamp



Schematic diagram of cross hanging plate

INSTALLATION STEPS









You can watch installation videos at the store fordetailed installation steps

Fernbedienung Benutzung



1. Schalten Sie das Licht ein/aus
2. Alles aus / Dekodierung
   Dekodierung.langes Drücken innerhalb von 5 Sekunden nach dem Einschalten, die Kodierung wird erfolgreich sein, wenn das Licht blinkt.
3. Umschalten der Farbtemperatur
4. Kleines Nachtlicht
5. Brigtness Subtraktion oder Addition
6. Subtraktion oder Addition der Farbtemperatur
7. 1-6 Lüfterstufen: 1. Gang ist der kleinste, 6 Gang ist der größte
8. F/R Gebläsedrehregler für Station und Rückwärtsgang (Einige Produkte haben diese Funktion nicht)
9. Zeitsteuerung 2 Stunden
10. LÜFTER AUS
11. Codeabgleich, langes Drücken innerhalb von 5 Sekunden nach dem Einschalten, das Licht blinkt, der Codeabgleich ist erfolgreich
    Hilfslicht (Einige Produkte verfügen nicht über diese Funktion)

IMPORTANT: PAIRING BETWEEN REMOTE AND RECEIVER

1. Turn “ON”the power supply and within 30 seconds press and hold the transmitters “FAN ON/OFF”button for 5 seconds and a“beep”will be heard this will then activate a successful pairing and all functions will work normally.

IMPORTANT:
pairing initial step must be performed within 30 seconds of power being turned on.

1(a). when pairing multiple fans please ensure the isolation switch or power supply to the first installed fan is turned off prior to pairing further fans e.g please pair one fan at a time

1(b). please ensure isolation switch is kept to the ON position, the isolation switch is not to be used as a light switch as this will damage and make the remote recevier inoperable

2. If the transmitter functions are not working please check the battery orientation and power level.Low battery voltage will affect the functions of your transmitter and operation of your fan.Other remote controls nearby using the same frequency may cause interference with the Fans receiver.

3. Please remove batteries from the transmitter if leaving unused for an extended period of time.

4. Remote supports 200w maximum on lighting side.

IMPORTANT REMINDERS

1. Please note: Receiver must be correctly installed in the mounting bracket on fan

2. When the transmitter cannot control the receiver, please check the battery has sufficient charge in the transmitter.

3. When the transmitter cannot control the receiver, please check if there is any existence of similar remote controlled products nearby, causing interference with each other.

4. Low power of battery will affect the sensitivity of the transmitter and the signal reception accordingly, must replace if the battery is getting low power.

5. Please take the battery out from the transmitter when leaving unused for a long time, to avoid battery leaks.

6. Isolation Switch “Must be connected in the line.”

7. When power is cut to the unit (via a blackout or otherwise) when power is restored the light will come on.

Before carrying out any cleaning or maintenance work, always make sure that the appliance is disconnected. LED lights are not removable. LED lights can only be used within the product delivery, they can not be replaced.

COMMON TROUBLESHOOTING

NOISE

When it is quiet(especially at night) you may hear occasional small noises. This is normal.
Please allow a 24-hour “breaking-in” period, most noises associated with a new fan disappear during the time.

Your fan may occasionally jerk forward or backward upon starting up.
This is normal and does not affect the fan operation.
Try these troubleshooting steps before contacting customer service.

Problem	Solution
Fan not spinning	• Make sure the fan is getting power. • Check your circuit breaker or fuse panel and wall switch for functionality. • Check to make sure the fan wires are correctly connected to the house wires. • Remote control must be paired with the fan within 1 minute after connecting the fan to the electricity. • Use a multi-meter and test the adapter wiring harness to see if there is any electrical output. • All the pin wiring on the circuit board must be inserted tight and in the correct position. • Remote needs to be paired with the fan first. • Make sure the fan blades spin freely. • If you're using a wall control,check the power to the breaker from your control and try working your ceiling fan manually. (Normal switch only for the fan power on/off)
Fan light not working	• Make sure LED wires are connected to the circuit board. • Make sure the whole fan is powered.
The fan is noisy and wobbling	• Check if the blade screws are NOT rubbing against any part of the motor housing. • Check the pin wires are NOT connected against any moving parts. • Check the down fan cup is NOT hitting the motor. • Confirm the canopy is NOT touching the ceiling while the fan is in operation. • Check the down rod is NOT slanted. • Tighten any loose screws on the light kit, fan blades, motor coupling, down rod, brackets and mounting hardware. • Confirm the hanger ball is firmly seated in the mounting bracket. • The ceiling beam must meet the minimum tensile test strength of 30KG for installation. • Make sure the blades and brackets are NOT bent or deformed. • Verify the wire connections are not rattling against each other. • Verify the fan blades are not cracked. If the fan blades are cracked, replace the damaged blades with a new blade set from the same brand as your ceiling fan to ensure compatibility. • Confirm the light kit is NOT slanting and hitting the motor.
The fan or light automatically turns on/off	• Confirm the circuit breaker is not malfunctioning. • Verify the wire connections are not frayed. • Check the app is not set to a timer or schedule. • Cut the fan power for 10 minutes then power on again. • All the pin wiring on the circuit board must be inserted tight and in the correct position.