

BATHTUB & SHOWER KIT

TECHNICAL DATA SHEET

SlipDoctors Bathtub & Shower Kit is an all-in-one treatment kit that contains everything you need to help make your bathtub or shower safe. This product is highly effective in areas that stay wet consistently. It is not a coating that can wear off, but a treatment that creates microscopic treads on the surface of the bathtub or tiled shower. Bathtub and Shower Treatment Kit will not damage or discolor your tub or shower and there will be no appearance change after application. In just 10 minutes, this treatment will help you prevent slip-and-fall accidents in your shower or bathtub for years.

Special Features

- Barefoot Friendly
- Increases Traction
- Fast & Easy Application
- Application Time 10 Minutes
- Not a Coating
- Long-lasting Results

Suggested Use

- Commercial and Residential
- Bathtubs
- Showers
- Hotels
- Spas
- Locker Rooms

Product Characteristics and Benefits

Surfaces*	Porcelain, ceramic, enamel, cast iron, steel and natural stone.
Color	Green solution
Mode of Application	Scrub pad (included)
Container Size	Two 1 oz bottles; 1-gallon bottle
Dry Time	N/A
Water Resistant	N/A
Stain Resistant	N/A
Product Type	Micro-treading solution
Coverage	One standard-size bathtub or standard-size shower
Storage	50°F (10°C) - 80°F (27°C); Protect from freezing
Shelf Life	5 years
Warranty	2 years
Removal	N/A
Disposal	Dispose of container and unused contents in accordance with local, state, and federal regulations.
Coefficient of Friction*	0.63 Wet DCOF - ANSI B101.3 0.65 Wet DCOF - ANSI A137.1 / A326.3 0.72 Wet SCOF - ANSI B101.1

*results may vary depending on surface and time of exposure



Precautions & Technical Support

Please refer to Safety Data Sheet (SDS) for detailed Precautions and First Aid Instructions.

Bathtub & Shower Kit Safety Data Sheet can be found at www.slipdoctors.com

Technical Support:

Please contact SlipDoctors at support@slipdoctors.com

** This product is not for use on fiberglass or acrylic bathtubs or showers.*



BATHTUB & SHOWER KIT

TECHNICAL DATA SHEET

Directions for Preparation, Application and Use

Read entire product label, Technical Data Sheet (TDS) & Safety Data Sheet (SDS) before using.

Safety Precautions	<ul style="list-style-type: none"> • Use in a well-ventilated area
Optional Safety Equipment	<ul style="list-style-type: none"> • Wear a long sleeve shirt • Eye protection • Nitrile glove (included)
Surface Preparation	<p>Clean the bathtub/shower using a general household cleaner. Rinse several times with clean water. Use a towel to dry the bathtub/shower completely.</p> <p>Avoid extended direct contact with metal surfaces. If possible, remove or cover drain to avoid contact with solution.</p>
Application Instructions	<p>Step 1: Pour contents of one bottle onto the bottom of a standard-size bathtub. (Use the second bottle when treating oversized tubs or showers).</p> <p>Step 2: Using the scrub pad, spread the product over the bottom of the bathtub or shower. The solution should cover the entire surface.</p> <p>Step 3: Allow the solution to sit for approximately 4-8 minutes, spreading the liquid to keep the surface wet. Do not allow the solution to dry on the surface.</p> <p>Step 4: If solution comes in contact with skin, metal or any other surface, wash off immediately.</p> <p>Step 5: Open the drain, and thoroughly rinse your bathtub/shower several times and allow to air dry. Enjoy your new slip-resistant bathtub or shower!</p>
Maintenance	<p>For general cleaning and maintenance, use a pH-neutral cleaner and soft bristle brush in a circular scrubbing motion to agitate the surface of your shower or tub.</p>



Warranty & Disclaimer

WARRANTY: All properly installed SlipDoctors products are guaranteed to increase the coefficient of friction of your surface for 2 years (provided surface preparation and cleaning procedures are followed and no contaminants are present). If at any time during the warranty period the treated surface should lose its coefficient of friction, SlipDoctors shall at its option replace any product that proves defective. This warranty applies only to the product itself. Neither the seller nor the manufacturer shall be liable for any injury, loss or damage direct or consequential, arising out of the use or the inability to use the product. Before using, user shall determine the suitability of the product for the intended use, and the user assumes all risk and liability whatsoever in connection therewith. No statement or recommendation not contained herein shall have any force or effect unless in an agreement signed by seller and manufacturer. Buyer assumes all risks and responsibility associated with disposal. SlipDoctors cannot eliminate all possibilities of slip-and-fall accidents. Please visit www.slipdoctors.com to find further warranty information. KEEP OUT OF REACH OF CHILDREN.

