### STARLIKE CRYSTAL

# EVO


### Made In Italy

## > Application

1	B	Empty completely all the contents of the catalyst (B) onto the paste (A).	
2		Mix at slow speed using an electric drill equipped with mixing paddle. Scrape the walls of the bucket to eliminate all parts of non-catalysed product.	
3	R	The joints must be dry. Introduce the mortar into the joints using the suitable green rubber float (art. 946GR) spreading diagonally across the joints. Remove the excess product.	
4		The grout must be cleaned while the product is still wet. Sprinkle clean water. Initial cleaning usir (art. 109/GBNC) making circular movements. Ensure no water enters the joints. Any adjustments t before cleaning with water.	5
5		Now perform a second cleaning with a rigid cellulose sponge (art. 128G0001).	
6	Litonet EVO Litonet Gel EVO	Any stains of the transparent product can be removed after 24 hours or after. Use HAZE REMOVER	R. Spread with the white felt.
7		Leave on for 15-30 minutes. Scrub the surface with the white felt.	
8		Rinse with clean water. Dry immediately with a clean cloth and do not wait for the evaporation of	the rinse water.

Mixture life:About 1 hour at T= +23°C / 73,4°F Application temperature:from +12°C to +30°C / From + 64,4°F to 73,4°F Recommended application temperaturefrom +18°C to +23°C / From 64,4°F to 73,4 Walkable after:24 hours at T= +23°C / 73,4°F Ready for use:5 days at T= +23°C / 73,4°F Storage time:24 months in original packaging, avoid freezing temperatures. Packaging: 1, 2.5 and 5 kg buckets Mixing ratios:Component A: 93.7 parts by weight - Component B: 6.3 parts by weight -The two components are pre-measured in their respective packaging Consistency of the mixcreamy grout Specific gravity of mix:1.55 kg/I Joint width:Up to 3 mm

#### ADVISED TOOLS









EXCLUSIVE DISTRIBUTOR FOR USA Tile Doctor www.TileDoctor.com 877-TileDoc (845-3362)