

BELL+HOWELL

**BIONIC**

• MULTI DIRECTIONAL •

**WORK LIGHT**

**1000**  
SUPER BRIGHT  
LUMENS!



**INSTRUCTIONS**

**WARNING! DO NOT SHINE  
DIRECTLY INTO EYES.**

## BATTERY INSTALLATION

**Do not mix old and new batteries.  
Do not mix Alkaline, standard or  
rechargeable batteries.**

1. Squeeze the tab on each side to remove Battery Compartment cover. See Diagram on right.
2. Insert total of 4 AA batteries following the correct polarity (+, -) marked inside the battery compartment. **All 4 batteries must be installed in order for the light to work.**
3. Replace the Battery Compartment cover. Snap in to close.



## USAGE - 3 Modes

Unfold the work light to the desired position.  
Refer to Diagram below for multiple angles.

Press the ON/OFF Button located on the side of the unit to turn on both lights.  
Press it again for only one light.  
Press it again for the other single light.  
Press it again to turn off the light.



## CLEANING

Wipe the outside of the work light with damp cloth. Do not use harsh or abrasive cleaning agents, as these may damage the surface of the unit.



## FULLY ADJUSTABLE ANGLES